

Velocity CONTROL PANEL

Operation and Maintenance Manual



CONTENTS Page


Controls and Indicators	4
System Operating Modes and Annunciation	7
Normal Condition (Quiescent)	7
Trouble Condition	7
Alarm Condition	8
Supervisory Condition	8
Disablement Condition	9
Test Condition	10
Multiple Conditions	10
Alarm Verification Conditions	10
Accessing the Panel	11
Basic user access (Access level 2a)	11
Full user access (Access level 2b)	11
Engineer Access (Access level 3)	11
Turning Off Access	11
Navigating the Panel Menus	12
Table View Screen	12
Data Field Screen	12
Text Keyboard	13
Number Keyboard	13
Acknowledge	14
Initial Panel Setup	15
Setting Date and Time	15
Creating an Installation Name	15
Passwords	16
Configuring the SLC Modules	16
Configuring Supervisory signals	17
Zone Labels	19
SLC Device Text and Zoning	19
SLC Device Options	22
Setting NCA & NCB Module Options	25
Setting ZMA & ZMB & MIM Module Options	26
Setting MRM Module Options	28
Event Logs	29
Programming	31
Buzzer Resound 24H Settings	31
Flash Mute Settings	33
Cause and Effect	33
Outputs and Delays	39
NAC Delays	39
NAC Time Limit Cut Out	39
SLC & Local/IO Relay Output Delays	40
Mains Trouble Relay Output Delay	40
Programming Delays	41
Switching Off Delays at Access Level 2	41

Day/Night Mode.....	42
Defining Day and Night Times	42
Setting Day-Time and Night-Time Delays	44
Setting Day-Time and Night-Time Detector Sensitivity	45
Indication of Day/Night Mode.....	46
Alarm Verification	47
Local indication of Verification	47
Alarm Verification Setup	47
Multiple Detector Operation	50
Multiple Detector Operation Setup	50
Positive Alarm Sequence.....	52
Positive Alarm Sequence Setup.....	52
Pre-Signal	54
Pre-Signal Setup	54
Disabling.....	56
Zone Disabling	56
SLC Device Disabling	58
Alarm Group Disabling.....	59
Global Mode Disabling	59
Alarm Group Mode	61
Local I/O (Module) Disabling	62
Test Mode.....	65
Why Use Test Mode?.....	65
To Programme a Zone into Test Mode	65
Networking.....	67
Network Typologies.....	67
Ring Network (Class A)	67
Bus Network (Class B)	67
Configuring the Network.....	68
Running the Network	69
Configuring the RS232 Panel Printer.....	70
Maintenance	71
Troubleshooting	73
SLC Trouble Finding	73
SLC Contents Trouble Finding.....	75
Power Supply Trouble.....	77
Earth Trouble	78
CPU Trouble.....	78
Local I/O Faults	79
Network Faults	80
Appendix A: User Menu Summary	81
Appendix B: Engineer Menu Summary.....	83
Appendix C: Cause and Effects Settings Summary	85

Controls and Indicators

Figure #1 below shows the control buttons, LED indicators and switch locations.

Figure #1



a) **LED: Alarm**

- Red LED.
- Flashes when there is an active alarm event present.
- On steady once acknowledged.
- Off when the alarm condition is cleared, and when the panel has been reset.

b) **LED: Supervisory**

- Yellow LED.
- Flashes when there is a supervisory event present.
- On steady once acknowledged.
- Off when the supervisory condition is cleared (some supervisory inputs may require a system reset if they are latched).

c) **LED: Trouble**

- Yellow LED.
- Flashes when there's a fault with a monitored circuit/system component or when a NAC device has been disabled.
- On steady once acknowledged.
- Off when the trouble condition has been cleared (some trouble signals may require a system reset if they are latched).

d) **LED: Alarm Silenced**

- Yellow LED.
- Flashes to indicate that the Notification Alarm Circuits and the Notification Alarm Devices are deactivated, but the panel is still in alarm.

- Off if the panel re-enters alarm, the system is reset, or if a drill is carried out.

e) **LED: Power**

- Green LED.
- On steady when the panel has power.
- Off when the panel has no source of power applied.

f) **LED: Controls Active**

- Yellow LED.
- Indicates that the user now has access to use either the function buttons or the LCD touch screen display (depending on access level).
- On when the user has entered the access level 2 user password, or when the user has entered the access level 3 engineers password.
- Off when either the access has timed out, or when the user/engineer has locked the panel.

g) **LED: Acknowledge**

- Yellow LED.
- Flashes when there are unacknowledged events.
- On steady when all current events have been acknowledged.
- Off when there are no events.

h) **LED: General Disablement**

- Yellow LED.
- On steady when any part of the system has been disabled.
- Off when there are no current disablements.

i) **LED: General Test**

- Yellow LED.
- On steady when any part of the system is in test mode.
- Off when there are no current circuits/devices in test mode.

j) **LED: NAC Trouble/Disablement**

- Yellow LED.
- On steady if there is a fault detected on an NAC circuit.
- On steady when an NAC has been disabled.
- Off when the NAC's are in the normal condition.

k) **LED: NAC Delay**

- Yellow LED.
- On when an NAC has been configured to delay its output.
- Off when there is no configured delay to the NAC's output.

l) **LED: NAC Active**

- Red LED.
- On when the output of any NAC is currently active.
- Off when there are no NAC's with their outputs active.

m) **LED: CPU Trouble**

- Yellow LED.
- On when there is an abnormal microprocessor running condition due to various unexpected phenomena.
- Off when the microprocessor is running correctly.

n) **Function Button: Silence Alarm**

- A minimum of Level 2 access (By entering the user password) is required.
- When the **SILENCE ALARM** key is pressed, the panel's Notification Alarm Appliances will be silenced.
- The **Alarm Silenced LED** will start flashing and remain until either the panel is reset, or until another alarm retriggers the notification appliances. The **RED ALARM LED** shall be maintained.
- NOTE: to silence the panels' internal buzzer, the alarm must be acknowledged.
- It also sends a 'SILENCE ALARM' message to the panel printer and history log.

o) **Function Button: ACK (Acknowledge)**

- A minimum of Level 2 access (By entering the user password) is required.
- When the ACKNOWLEDGE button is pressed, the control panel will silence its internal sounder (buzzer). *The internal buzzer will only be silenced after all events have been acknowledged.*
- Change all related active LED indicators from flashing to steady.
- Sends acknowledgment confirmation the LCD status screen.
- The acknowledge message is sent to the printer and the history log.
- The button is used to acknowledge and silence the internal buzzer for Alarm, Supervisory and Trouble events.
- Pressing the ACK button will acknowledge events cross network.

p) **Function Button: Scroll Display (Scroll Acknowledge Display)**

- If there is an event waiting to be acknowledged, then the Acknowledgment LED will be lit.
- Press the scroll button to view each current Alarm, Supervisory and trouble event on the panel.
- The priority will be (Alarm, Supervisory, and then Trouble).

q) **Function Button: Reset**

- A minimum of Level 2 access (By entering the user password) is required.
- Pressing the **RESET** button will return the panel to normal operating mode, clear any off-normal condition from the status display; restore the alarm and trouble relays to their normal states; extinguish all status LEDs except the green POWER LED, and yellow test/disablement/delay LED's.
- If any alarm or trouble still exists after you press the SYSTEM RESET button, all NACs, control outputs, and panel audio and visual indicators will reactivate.
- The reset message is sent to the printer and the history log.
- The reset button will not operate unless all the events have been acknowledged (*User level only*). When in Admin (Engineering level), the panel can be reset without acknowledging all events.
- The reset button will not operate if any NAC devices are active.

r) **Function Button: Drill**

- A minimum of Level 2 access (By entering the user password) is required.
- To start a drill, press the Drill button.
- Using the DRILL button will manually activate all silenceable outputs and Notification Appliance Circuits.
- It will not activate the alarm relays.
- It creates a history log entry of the drill and also sends it to installed printers.
- The drill can be cancelled via a press of the SILENCE ALARM button, and will also cancel if the panel receives an ALARM or SUPERVISORY event.

s) **4.3" Touch Screen Display**

- Full colour resistive touch screen.
- Designed to make status information clear and system control functions simple to operate.
- Each system event presents the user with a message describing the location of the alarm report and the type of event (manual alarm, smoke, or heat).
- **NOTE: To help increase the lifetime of the LCD display, the screen will go into standby mode if left idle for 10 minutes. The panel will still be fully operational and any event will cause the screen to wake up. The screen won't timeout into standby mode if there are any current events on the panel.**

t) **Internal Buzzer**

- Gives an audible indication if there is an alarm, trouble or supervisory event.
- Audible distinction between alarm and trouble/supervisory provided.
- The internal buzzer will only be silenced after all events have been acknowledged.

System Operating Modes and Annunciation

During normal operation the panel will be in one of the following states depending on the status of the devices connected to the panel, and user intervention. Below is a summary of the different conditions:

Normal Condition (Quiescent)

The following functions will be performed at regular intervals when in normal mode:

- Supervises all SLC devices, network devices and the notification appliance circuits.
- Checks for valid replies, alarms, troubles, etc.
- Checks for power supply and battery condition.
- Refreshes LCD displays and updates time.
- Scans keypad for System RESET.
- Supervises Network communications.
- Performs time-scheduled actions (day/night sensitivity and on/off schedules).

A typical normal display would be as illustrated below:



In the quiescent condition, the panel displays:

- System Healthy
- Velocity Logo
- Panel Site Name
- Time & Date


Trouble Condition

The following functions will be performed when in the trouble condition:

- Will cause the panel's internal buzzer to sound with a pulsed output.
- The general Trouble LED will illuminate and flash.
- Any relevant Trouble LED's will illuminate.
- A trouble message will be displayed on the LCD screen.
- The trouble relays will be switched.
- The message is sent to the history log and printer.

If there is a trouble signal indicated from an addressable SLC device, the reported message will show device address, zone and the TRM port information to aid in locating the problem. The time and date of the trouble indication will also be shown to aid in record keeping.

A typical trouble display would be as illustrated below:



On the screen, the panel shows:


- Trouble Icon
- Number of trouble events
- Details of trouble events in chronological order (showing trouble type, zone number & label, device address & label)
- Scroll arrows for displaying further events (if there are any).

Alarm Condition

The following functions will be performed when in the alarm condition:

- Will cause the panel's internal buzzer to sound with a steady output.
- The general Alarm LED will illuminate and flash.
- The LCD displays the Alarm along with the device name, type, address, associated zones and time/date.
- Alarms latch and are not allowed to clear automatically.
- Alarms activate cause & effects if programmed.
- Alarm relays are activated.
- The trouble relays are not activated.
- Stores event in history log and sends message to printer.

A typical alarm display would be as illustrated below:



On the screen, the panel shows:

- Fire Icon
- Number of zones in alarm
- Number of devices in alarm
- First & last zones in alarm
- Details of alarms in chronological order (showing device type, Zone number & label, Device address & label)
- Scroll arrows for displaying further events

Supervisory Condition

The Supervisory condition can be configured as latching or non-Latching for each supervisory input.


The following functions will be performed when in the supervisory condition:

- Will cause the panel's internal buzzer to sound with a pulsed output.
- The general Supervisory LED will illuminate and flash.
- The LCD displays the Supervisory status label along with the device name, type, address, associated zones and time/date.
- Any supervisory relays are activated.
- The alarm relay is not activated.
- The trouble relay is not activated.
- Silenced alarms are not resounded.
- Stores event in history log and sends message to printer.

If the supervisory input is configured as non-latching, and there are no active trouble or alarm events, when the supervisory event clears, the screen will clear.

If the supervisory input is configured as latching, when the supervisory event clears, the screen will display Local supervisory off, and the panel will need to be reset to clear the screen.

A typical supervisory display would be as illustrated below:



On the screen, the panel shows:

- Supervisory Icon
- Number of supervisory events
- Details of supervisory in chronological order (showing type, zone number & label, device address & label)
- Scroll arrows for displaying further events

Disablement Condition


Disablements are indicated with the general disablement LED, and a mixture of LCD/LED indications.

In this example, zone 1 is disabled. The panel shows that one zone is disabled, and that the 10 Loop (SLC) devices and 2 module inputs/outputs in that zone are also disabled.

Press the zone icon, SLC device icon or local I/O for details of the disablements.


Note:

Disabling a NAC device will cause the panel to enter the trouble condition, and switch its trouble relays.




In this example, there is a single SLC addressable device disabled.


Press the Device icon for details of the disablement




In this example, one of the Inputs on a Zone Monitor Class B module has been disabled.





Pressing one of the zone disablement icons will give further details about which zone has been disabled.




Or pressing the disabled SLC devices icon will give details about which devices are disabled.




Test Condition

<p>In this example, one zone (zone 12) is in test mode. A number of zones can be put into test at the same time if required. The test can be silent, or with sounders. If the sounder option is chosen, only sounders within the same zone as the test device are operated.</p>	
<p>As devices are tested, the screen changes to show the recent tests. Use the arrow to scroll to view older tests if required.</p>	

Multiple Conditions

<p>In the event of multiple conditions, the panel will display the highest priority event. It will display the presence of suppressed events as icons on the top right of the screen. The number of events for each category is shown on the icon. To display any of the suppressed events, press the icon of that event.</p> <p><i>(Priority: Alarms >Supervisory>Trouble>Disablement/Test)</i></p>	
---	--

Alarm Verification Conditions

<p>If Alarm verification has been enabled on the control panel, the panel will indicate the verification as a pop-up window, giving the device type, along with its address, text label and zone.</p> <p>If the alarm clears, the panel will clear it's screen when the verification time ends.</p> <p>If the alarm is still present, the panel will confirm this as an alarm, and display its usual alarm screen.</p>	
--	--

Accessing the Panel


The VELOCITY panel has 2 user access levels and one installer access level.

Basic user access (Access level 2a)

Tap LCD. Select user icon . Enter user access code (Default 0001)

This allows the user to have access to the main control buttons, to silence alarms, acknowledge events and reset the panel.

It is indicated by a steady Controls Active LED, and an open padlock icon in the bottom left corner of the LCD screen.



Full user access (Access level 2b)


From access level 2a press the menu access icon.

This allows the user to view the user menus, to view device status, event logs etc.


It is indicated by a steady Controls Active LED, and an open padlock icon in the bottom left corner of the LCD screen.




Engineer Access (Access level 3)


Tap LCD. Select Engineer icon . Enter the Engineer access code (Default 9999). This allows the engineer to configure the panel, set zone & device text, allocate zones, enter panel cause & effect etc.

It is indicated by a Controls Active LED, and an open padlock icon in the bottom left corner of the LCD screen.




Turning Off Access

If the panel is in one of the menus, press the exit menu icon  in the bottom left corner.

Press the padlock icon  in the bottom left corner. The controls active LCD will turn off and the padlock icon will turn off.


(To help keep the panel secure, access will automatically timeout if the panel is left idle for approx. 5 minutes)




Navigating the Panel Menus

The Velocity panel has 2 menus, user and engineer.

Entering the user code (Default 0001) accesses the user menu. Entering the Engineer password (Default 9999)

enables access level 3. Press the access menu icon  to access the Engineer menu.



The menus are in the form of icons with a text label underneath. To select a particular menu, press the relevant icon.

The sub screens are in the form of tabbed screens if there is more than one sub-option, the data will either be displayed in a table, or as separate data fields, depending on the function of the sub screen





Table View Screen


Information is presented in a table, there is editable data (e.g. device labels), and non-editable data (e.g. device types). Tapping on an editable data field will allow it to be edited.



Data Field Screen


Information is presented in data fields, the data will either be values, or option buttons.


Clicking on the field will allow it to be edited



Text Keyboard


Used to enter text. Use <- and -> to position the keyboard. Press the circle at the end of the text field to delete text as required. The '123' key brings up the numeric keyboard. And the 'CAP' key turns on the caps lock.

Press  when finished to confirm the text entry.



Number Keyboard

Use the up & down Icons to increase or decrease the number, or enter the number via the keypad.














Acknowledge

When an Alarm, Supervisory or Trouble event occurs in the system, the display enters the off-normal mode automatically. The events are displayed in priority order (Alarm, Supervisory, and Trouble), the local audible buzzer sounds and the appropriate LED's will blink. After all events have been acknowledged, the buzzer will deactivate and the associated LED will stop flashing and remain on continuously. If the panel is networked, the events will be acknowledged across the network. The way the panel responds to acknowledgement will depend on the current access level.

Admin (Engineer Level): Events can be mass acknowledged, pressing ACK will mass acknowledge each event by event type.





User (User Level): Events can only be acknowledged individually, there is no mass acknowledge capability.

<p>When the panel receives an event that needs to be acknowledged, it will display the relevant event status screen.</p> <p>Events that are unacknowledged will be highlighted (Yellow for Trouble, Red for Alarm and Blue for supervisory.).</p> <p>The event that is next in the queue to be acknowledged will be blinking.</p>	
<p>Press the  (ACK) button to acknowledge the blinking event.</p> <p>When an event has been acknowledged, it will no longer be highlighted and blinking, instead it will change to solid white. The panel internal buzzer will also be silenced (if there are no remaining unacknowledged events).</p> <p>If there are multiple events in the queue to be acknowledged, press  &  to scroll through the pages. The  (SCROLL DISPLAY) button can also be pressed to scroll through event pages.</p>	
<p>Once all events have been acknowledged, panel status LED's (Alarm, Supervisory, Trouble) and the Acknowledgment LED, will change from flashing to steady to indicate that there are no pending events to be acknowledged. The panel internal buzzer will also be silenced when there are no remaining events to be acknowledged.</p>	
<p>If there are multiple event types waiting to be acknowledged on the panel, press either the ,  or  icons to navigate to the required event screen.</p>	


Initial Panel Setup

The Velocity panel is supplied configured ready for installation. But there are a few settings that may need to be altered.

Setting Date and Time

<p>Press the screen. The panel prompts for a user and password. Select Engineer, and enter the Engineer (Access Level 3) password (default is 9999)</p> <p>Press the access menu icon, followed by the 'system' icon .</p>	
<p>Select the Clock tab. Edit the time and date as required.</p> <p>Press the exit button to leave the menu.</p>	
<p>Pressing the + or - changes the setting by 1. To make a bigger adjustment, press the number field and a keypad appears to enter the new value. Press the green tick to accept the value. When all values are correct, press the exit menu icon.</p>	

Creating an Installation Name

<p>From the installer menu, press the 'system' Icon. Then select the strings tab.</p> <p>Enter the Site Name, Installation/Maintenance Company and their contact number.</p> <p>Note: The site name that is entered here will be what is displayed on the panel home screen.</p> <p>Press the exit button to leave the menu. Press the green tick to confirm the changes.</p>	
--	--

Passwords

From the installer menu, press the 'system' icon.

Select the USERS tab.


To change a user name, tap a user field.

To change a password, tap a password field. The panel will prompt to enter the new password twice.

To delete a user, enter the password as blank.

Any unused user should have the password left blank

Press the exit button to leave the menu. Press the green tick to confirm the changes.




Configuring the SLC Modules

Press the screen. The panel prompts for a password.


Enter the Engineer (Access Level 3) password (default is 9999)

Press the 'Loop' Icon.




On the module selection screen, select the correct SLC port number. The port number is shown in the brackets on the left. When you select the SLC it will become highlighted. Press the green tick to confirm the selection.

The port number will be labelled on the TRM PCB inside the panel and are also shown in the Velocity Installation manual (Doc: GLT-261-7-1).



The panel will proceed to search and learn the loop.



When the configuration is complete, the panel displays a summary of the devices found.

Loop Report			
Summary Detailed EN54 - 13			
Total	: 134	Double address	: 0
DIP-SCI	: 33	DOT-SCI	: 2
DPH	: 21	H2	: 19
MCP	: 25	PY	: 18
SB	: 10	SCM-SCI	: 0
		Unknown	: 0
		DOP-240-SCI	: 1
		H2-H	: 0
		PYH	: 0
		SCM-A-SCI	: 0

To view details of the configuration, click the detail tab.

This shows the device type found at each address, and also shows whether it was seen from Side A or Side B (to help locate CABLE BREAKS). It also shows if the device seen is different to the previous database [!!] (i.e. has the device type been changed), or if it is the same as previously configured [=]

Press to exit and either confirm or dismiss the changes.

Loop Report				
Summary Detailed EN54 - 13				
Address	Type	Side A	Side B	dBase
1	PY	X	X	=
2	DPH	X	X	=
3	H2-H	X	X	=
4	H2-H	X	X	=

Configuring Supervisory signals

The Velocity MMP system allows panel-based Inputs (VL-MIM), and SLC loop based inputs (VDOT-DIP-SCI) to be configured to report alarm or supervisory conditions. When configured to report a supervisory condition, Latching (message stays on screen if event clears), or Non-latching (Panel returns to normal, clearing LEDs and screen) can be selected.

Configuring VL-MIM

From the ENGINEER MENU, press the Local I/O Icon.

The panel will show the module selection screen. Select the required port number. The port number is shown in the brackets on the left. When you select a module it will become highlighted. The up and down arrows can be used to cycle through pages. Press the green tick to confirm the selection.

Panel Designations:

VL-MIM (Multi Input – 6 x Class B) = Input Class B

The port number will be labelled on the TRM PCB inside the panel and are also shown in the Velocity Installation manual (Doc: GLT-261-7-1).

The module settings screen will be displayed.

In this example, the input address is shown as: **(5.1)**. The first number represents the TRM port (The RJ45 port on the TRM PCB that the module is plugged into). The second number represents the input on the module itself.

E.g. a MIM that is plugged into TRM port 5 would have the following addresses:

(5.1) = TRM Port 5, Input 1	(5.2) = TRM Port 5, Input 2
(5.3) = TRM Port 5, Input 3	(5.4) = TRM Port 5, Input 4
(5.5) = TRM Port 5, Input 5	(5.6) = TRM Port 5, Input 6

4 Module selection	
(3)	ZONE CLASS A
(4)	ZONE CLASS B
(5)	INPUT CLASS B

5 INPUT CLASS B	
(5.1)	: MODULE 5 PORT 1
Zn/Ag	: 1
Type	: Alarm
Mode	: <input type="radio"/> Disabled <input checked="" type="radio"/> Enabled

You can set each input to either an:

- Alarm
- Supervisory (Latching)
- Supervisory (Non latching)

(See the *System Operating Modes and Annunciation* section for more details on how each of these settings affects the panel operation).

To change the input mode, simply press on + button to cycle through the options.

When you have finished configuring the module input, you can press the or arrows to change to the next input port number on the module, or press to exit and either confirm or dismiss the changes.

Configuring VDOT-DIP-SCI as Supervisory

To configure an input of a VDOT-DIP-SCI as Supervisory (Latching) or Supervisory (Non-Latching), click the device icon, and select the required loop.

Then in the device explorer screen, click the options tab.

Scroll to the required module, then tap its options in the option column.

Addr	Type	Point text	Options
1	DIP-SCI	Main Entrance	Options
2	PY	Reception	Options
3	DPH	Canteen	Options
4	DOP-SCI	Admin Hall	Options

Click Input event + until it displays (Supervisory[Latch]) or (Supervisory[Non Latch]) as required

Other available options:

Led Flash:
(Off) / (On)

Input Style:
(ClassB [NO]) / (ClassA [NO]) / (ClassB [NC/SC]) / (ClassB [NO/SC]) / (ClassA [NO/SC])

Pri. Poll:
(Off) / (On)

Note: Turning on priority polling will make the panel prioritise events from this device. This can only be used on 50 devices per loop.

Note: to operate an output during a supervisory, program suitable cause and effect for Supervisory on event. If the output is required to turn off when the supervisory clears, you will need to program suitable cause and effect for the Supervisory off event (see PROGRAMMING: CAUSE AND EFFECT section of this manual)

Zone Labels

All fire alarm systems must be subdivided into zones, which represent the geographical areas of the building. The Velocity fire system allows any number of devices to be allocated to a zone. However, it is assumed that a zone will not contain more than 32 fire detectors and/or manual call points, since this would correspond to an unacceptably large search area. The Velocity panel has 254 zones. There is capability in some panel models (MMP10/64 & MMP26/64) to have LED indications for the first 64 zones. When a fire is reported, the zone number in which the fire is located is indicated on the panel touch screen display. In addition to its numerical description, a zone can be identified by a text label, e.g. 3rd floor west ext. If the installer associates a text label with each zone of a fire alarm system, this will be displayed on the LCD when a fire is detected. The maximum length of the zone text label is 39 characters.


<p>Enter the engineer password and select the 'zone' icon.</p> <p>Press on the zone that you wish to edit.</p>	<div><div>Zone Explorer</div><table><thead><tr><th></th><th>Text</th><th>Devices</th><th>In</th></tr></thead><tbody><tr><td>1</td><td>ZONE 1</td><td>28</td><td>Edit</td></tr><tr><td>2</td><td>ZONE 2</td><td>18</td><td>Edit</td></tr><tr><td>3</td><td>ZONE 3</td><td>11</td><td>Edit</td></tr><tr><td>4</td><td>ZONE 4</td><td>7</td><td>Edit</td></tr><tr><td>5</td><td>ZONE 5</td><td>10</td><td>Edit</td></tr></tbody></table><div><div></div><div></div><div></div></div></div>		Text	Devices	In	1	ZONE 1	28	Edit	2	ZONE 2	18	Edit	3	ZONE 3	11	Edit	4	ZONE 4	7	Edit	5	ZONE 5	10	Edit
	Text	Devices	In																						
1	ZONE 1	28	Edit																						
2	ZONE 2	18	Edit																						
3	ZONE 3	11	Edit																						
4	ZONE 4	7	Edit																						
5	ZONE 5	10	Edit																						
<p>This will show the zone explorer settings menu. Press on the zone text field to edit it.</p> <p>The and arrows can be pressed to cycle through the zone numbers.</p>	<div><div>Zone Explorer</div><div><div>Zone (001) : ZONE 1</div><div>Devices : 028</div><div>Zone mode : <input checked="" type="radio"/> Enabled <input type="radio"/> Disabled <input type="radio"/> Test <input type="radio"/> Test + So</div></div><div><div></div><div></div><div></div></div></div>																								
<p>Use <- and -> to place the keyboard cursor, and to delete unwanted text. Type the zone name, and press exit when done. Repeat for all required zones.</p>	<div><div>Zone Explorer</div><div><div>Basement</div><div><div>q w e r t y u i o p</div><div>a s d f g h j k l</div><div>z x c v b n m .</div><div>CAP 123 < -></div></div><div><div></div><div></div></div></div></div>																								

SLC Device Text and Zoning


Velocity is an addressable panel, i.e. it will indicate the address or location of a fire that has been detected. The address number of each point or device on the loop has already been set with the address programming toolVDOT-AD2. See Manual GLT-303-7-1 for details. The installation engineer must now assign a label or location for each device, e.g. ROOM 107. A maximum of 24 characters can be used for each label. Devices can also be allocated to their correct zones at this stage.

From the ENGINEER MENU, press the 'Devices' icon.


Press the text field of the device to be edited.




The Panel shows the on screen keyboard. Enter the required device label (up to 24 characters). Press the green tick to confirm the text.



Press the 'zone' field to edit the device's zone number if required.




Edit another device, or press  to exit the device list and save the changes.






The Device list screen also shows the current mode of each device, i.e. ENABLED or DISABLED

Press the MODE field of a device to toggle its state between enabled and disabled.




The analogue values can be displayed by pressing the 'Real Time' tab.

Press the  &  arrows to scroll through the device list.





Device specific options can be set via the 'Options' tab. See following section (SLC Device Options) for details.


Press the Options field for the required device to edit its options.




The Add / Remove tab allows devices to be manually added or removed from the system. This is useful if it is not possible to perform a loop learn (e.g., if a detector is to be changed to a different model, and the replacement is not available, or, if the loop is disconnected to perform maintenance / repair work).




To manually remove a device, tap the device so that it's highlighted yellow, then press the delete icon .



To manually add a device, press the add icon .





Select the address and device type of the item being added.






Enter the point text for the device, and select which zone it will be in.








SLC Device Options

Each addressable Velocity device has a number of configuration settings that can be programmed at the panel. The configuration screen is accessed by selecting the device on the options tab. The options for each device are:-

Device	Options
VDOT-H2 & VDOT-H3 <i>(Addressable Heat Detector)</i> <u>Available options:</u> Led Flash: (Off) / (On)	
VDOT-H2-H & VDOT-H3-H <i>(Addressable High Heat Detector)</i> <u>Available options:</u> Led Flash: (Off) / (On)	
VDOT-DPH <i>(Addressable Dual Optical/Heat Detector)</i> <u>Available options:</u> Led Flash: (Off) / (On) Day settings: (Opt. On) / (Opt. Off) (Heat On) / (Heat Off) Night settings: (Opt. On) / (Opt. Off) (Heat On) / (Heat Off)	
VDOT-DOP-AC240-SCI <i>(Addressable Relay Dual Output Module for AC240V with SCI)</i> <u>Available options:</u> Led Flash: (Off) / (On)	





<p>VDOT-DOP-SCI (Addressable Relay Dual Output with SCI)</p> <p><u>Available options:</u> Led Flash: (Off) / (On)</p>	
<p>VDOT-DIP-SCI (Addressable Dual Input Module with SCI)</p> <p><u>Available options:</u> Led Flash: (Off) / (On)</p> <p>Input Style: (ClassB [NO]) / (ClassA [NO]) / (ClassB [NC/SC]) / (ClassB [NO/SC]) / (ClassA [NO/SC])</p> <p>Input Event: (Alarm) / (Supervisory[Latch]) / (Supervisory[Non Latch]) / (Trouble)</p> <p>Pri. Poll: (Off) / (On) <i>Note: Turning on priority polling will make the panel prioritise events from this device. This can only be used on 50 devices per loop.</i></p>	
<p>VDOT-ZMU-SCI (Addressable Zone Monitor Module with SCI)</p> <p><u>Available options:</u> Led Flash: (Off) / (On)</p> <p>Input Style: (ClassB [NO]) / (ClassA [NO]) / (ClassB [NO/SC]) / (ClassA [NO/SC])</p> <p>Pri. Poll: (Off) / (On) <i>Note: Turning on priority polling will make the panel prioritise events from this device. This can only be used on 50 devices per loop.</i></p>	
<p>VDOT-SB (Addressable Sounder base)</p> <p><u>Available options:</u> No options available</p>	
<p>VDOT-PYH (6th Edition) & VDOT-PYH3 (7th Edition) (Addressable Multisensory Detector)</p> <p><u>Available options:</u> Led Flash: (Off) / (On)</p> <p>Day settings: (Opt. Normal) / (Opt. High) / (Opt. Low) / (Opt. Off) (Heat On) / (Heat Off)</p> <p>Night settings: (Opt. Normal) / (Opt. High) / (Opt. Low) / (Opt. Off)</p>	

<div>(Heat On) / (Heat Off)</div> <div> VDOT-PY(6th Edition) & VDOT-PY3 (7th Edition) <i>(Addressable Photoelectric Smoke Detector)</i> </div> <div> <div>Available options:</div> <div>Led Flash:</div> <div>(Off) / (On)</div> <div>Day settings:</div> <div>(Opt. Normal) / (Opt. High) / (Opt. Low)</div> <div>Night settings:</div> <div>(Opt. Normal) / (Opt. High) / (Opt. Low)</div> </div>	
<div> VDOT-MiniIP <i>(Addressable Photoelectric Smoke Detector)</i> </div> <div> <div>Available options:</div> <div>Input Style:</div> <div>(Class B [NO]) / (Class B [NC/SC]) / (Class B [NO/SC])</div> <div>Input Event:</div> <div>(Alarm) / (Supervisory [Latch]) / (Supervisory [Non Latch]) / (Trouble)</div> <div>Pri. Poll:</div> <div>(Off) / (On)</div> <div>Note: Turning on priority polling will make the panel prioritise events from this device. This can only be used on 50 devices per loop.</div> </div> <div> <div>VDOT-MCP MODE:</div> <div>To change a MiniIP into a MCP device type, press the </div> <div>icon then  to accept the changes.</div> </div>	
<div> VDOT-MCP <i>(Addressable Manual Call Point)</i> </div> <div> <div>Available options:</div> <div>No options available</div> </div>	

Setting NCA & NCB Module Options

The below is an example on how to change the VL-NCB options. The procedure to change the settings for the VL-NCA is the same.

Note that the cause & effect for the Velocity MMP panel has 3 tone options for the NACs: ANSI -3 tone, March tone and continuous.

<p>From the ENGINEER MENU, press the Local I/O Icon.</p> <p>The panel will show the module selection screen. Select the required port number. The port number is shown in the brackets on the left. When you select a module it will become highlighted. The up and down arrows can be used to cycle through pages. Press the green tick to confirm the selection.</p> <p><i>Panel Designations:</i> VL-NCA (NAC – 1 x Class A) = NAC Class A VL-NCB (NAC – 2 x Class B) = NAC Class B</p> <p>The port number will be labelled on the TRM PCB inside the panel and are also shown in the Velocity Installation manual (Doc: GLT-261-7-1).</p>	
<p>The module settings screen will be displayed.</p> <p>In this example, the output address is shown as: (3.1). The first number represents the TRM port (The RJ45 port on the TRM PCB that the module is plugged into). The second number represents the output on the module itself.</p> <p>E.g. A NCB that is plugged into TRM port 3 would have the following addresses:</p> <p>(3.1) = TRM Port 3, Output 1 (3.2) = TRM Port 3, Output 2</p>	
<p>To change the text label of a module output, press on the text label field. This will display the panel keyboard. Enter the required text name, and then press the green tick to confirm.</p>	
<p>Each output can be assigned to an alarm group. To change the alarm group, press either the + or – button to increase or decrease the group number.</p> <p>You can also type in the number via the panel numerical keyboard, to do this press on the zone number field. Type in the required alarm group number and press the green tick to confirm.</p>	

You can change the type of each output to either 'Sounder', 'Bell' or 'Voltage'.

Sounder

Provides power for, and handles communications to the non-addressable notification appliances (horns and sirens). Sounder mode provides a synchronized output (on velocity NAC devices only). It provides a steady 24V, with sync pulses once per second.

Bell


Provides a 24v output for use with mechanical fire alarm bells. This output will pulse the 24V on and off to achieve the required sound pattern. This option is unsynchronized.

Voltage


Provides a continuous 24v DC output for use with auxiliary equipment.

To change the output type, press on the + button to cycle through the options.

(NOTE: When NCA/NCB has been set to 'Voltage' mode, the module '24V ON' LED will be lit [Green constant]). When it is set to Bell, the 24V on LED will be flashing.



When you have finished configuring the module output, you can press the or arrows to change to the next output number on the module, or press to exit and either confirm or dismiss the changes.



Setting ZMA & ZMB & MIM Module Options

The below is an example on how to change the VL-ZMB options. However, the procedure to change the settings for the VL-ZMA & VL-MIM is the same.


From the ENGINEER MENU, press the Local I/O Icon.

The panel will show the module selection screen. Select the required port number. The port number is shown in the brackets on the left. When you select a module it will become highlighted. The up and down arrows can be used to cycle through pages. Press the green tick to confirm the selection.

Panel Designations:

VL-ZMA (Zone Monitor – 3 x Class A) = Zone Class A
 VL-ZMB (Zone Monitor – 6 x Class B) = Zone Class B
 VL-MIM (Multi Input – 6 x Class B) = Input Class B

The port number will be labelled on the TRM PCB inside the panel and are also shown in the Velocity Installation manual (Doc: GLT-261-7-1).



The module settings screen will be displayed.

In this example, the input address is shown as: **(4.1)**. The first number represents the TRM port (The RJ45 port on the TRM PCB that the module is plugged into). The second number represents the input on the module itself.

E.g. a ZMA that is plugged into TRM port 3 would have the following addresses:

(3.1) = TRM Port 3, Input 1

(3.2) = TRM Port 3, Input 2

(3.3) = TRM Port 3, Input 3

4 ZONE CLASS B

I/O

(4.1) : MODULE 4 PORT 1

Zn/AG : 1

Type : Alarm

Mode : ☐ Disabled ☒ Enabled

To change the text label of a module input, press on the text label field. This will display the panel keyboard. Enter the required text name, and then press the green tick to confirm.

4 ZONE CLASS B

I/O

BEAM DETECTOR

q w e r t y u i o p
a s d f g h j k l
z x c v b n m .
CAP 123 < >

Each input can be assigned to a zone. To change the zone, press either the + or – button to increase or decrease the zone number.

You can also type in the number via the panel numerical keyboard, to do this press on the zone number field. Type in the required zone number and press the green tick to confirm.

4 ZONE CLASS B

I/O

10

1 2 3 4 5
6 7 8 9 0

You can set each input to either an:

- Alarm
- Supervisory (Latching)
- Supervisory (Non latching)

(See the *System Operating Modes and Annunciation* section for more details on how each of these settings affects the panel operation).

To change the input mode, simply press on + button to cycle through the options.

4 ZONE CLASS B

I/O

(4.1) : BEAM DETECTOR

Zn/AG : 10

Type : Supervisory [Latch]

Mode : ☐ Disabled ☒ Enabled

When you have finished configuring the module input, you can press the or arrows to change to the next input port number on the module, or press to exit and either confirm or dismiss the changes.

4 ZONE CLASS B

I/O

(4.2) : MODULE 4 PORT 2

Zn/AG : 1

Type : Alarm

Mode : ☐ Disabled ☒ Enabled

Setting MRM Module Options


From the ENGINEER MENU, press the Local I/O Icon.

The panel will show the module selection screen. Select the required module. The TRM port number is shown in the brackets on the left. When you select a module it will become highlighted. The up and down arrows can be used to cycle through pages. Press the green tick to confirm the selection.

Panel Designations:

VL-MRM (Multi Relay – 3 x Form C) = Relay

The port number will be labelled on the TRM PCB inside the panel and are also shown in the Velocity Installation manual (Doc: GLT-261-7-1).




The module settings screen will be displayed.


In this example, the output address is shown as: **(1.1)**. The first number represents the TRM port (The RJ45 port on the TRM PCB that the module is plugged into). The second number represents the output on the module itself.

E.g. a MRM that is plugged into TRM port 1 would have the following addresses:

- (1.1) = TRM Port 1, Output 1
- (1.2) = TRM Port 1, Output 2
- (1.3) = TRM Port 1, Output 3




To change the text label of a module output, press on the text label field. This will display the panel keyboard. Enter the required text name, and then press the green tick to confirm.



Each output can be assigned to an alarm group. To change the group, press either the + or – button to increase or decrease the group number.

You can also type in the number via the panel numerical keyboard, to do this press on the Zn/AG number field. Type in the required alarm group number and press the green tick to confirm.




You can change the mode of each output to Programmable, Alarm, Trouble or Supervisory.

Programmable:

Relay will only react to cause & effects that have been programmed into the panel. This is the only setting that allows the relay to be disabled.

Alarm:

Relay will act as a common alarm relay, and will react to ANY alarm condition on the panel. Cannot be disabled or controlled by cause & effects.






Trouble:


Relay will act as a common trouble relay, and will react to ANY trouble condition on the panel. Cannot be disabled or controlled by cause & effects. Relay will become normally energised.

Supervisory:

Relay will act as a common supervisory relay, and will react to ANY supervisory condition on the panel. Cannot be disabled or controlled by cause & effects.

To change the output type, press on the + button to cycle through the options.


When you have finished configuring the module output, you can press the  or  arrows to change to the next output number on the module, or press  to exit and either confirm or dismiss the changes.



Event Logs

The Velocity event log has a capacity of storing **8032** events. It saves all alarm, trouble, supervisory and test events that occur on the system.

From the ENGINEER MENU, press the 'log' icon. The panel will display the log file.








Trouble events are shown with a YELLOW highlight.

The highlighted section gives the time, date and the general trouble information.

The table shows more detail of the trouble event.

The left hand column shows the event number.

Log file	
136	
004	2018/08/07 11:27 --> POWER SUPPLY FAULT
	MAINS SUPPLY FAULT
005	2018/08/07 11:30 --> DEVICE NOT RESPONDING - MINI-IP
	Point : 137 - LOOP DEVICE 137
	Zone : 006 - ZONE 6
006	2018/08/09 15:30 --> MODULE REMOVED - (06)
	ZONE CLASS B

<p>Operational events are shown with a MAGENTA highlight.</p> <p>The highlighted section gives the time, date and the operation information.</p> <p>The left hand column shows the event number.</p> <p>Some operational events are able to show more detailed information when “Click here for more information” is shown. Clicking this will display a table that will show the operational event in more detail.</p>	
<p>Alarm events are shown with a RED highlight.</p> <p>The highlighted section gives the time, date and the device type that has caused the alarm.</p> <p>The table shows more detail of the Alarm event (Address, device text label, zone number, zone text label).</p> <p>The left hand column shows the event number.</p>	
<p>Test events are shown with a GREEN highlight.</p> <p>The highlighted section gives the time, date and the device type that has caused the alarm.</p> <p>The table shows more detail of the test event (Address, Device text label, zone, zone text label).</p> <p>The left hand column shows the event number.</p>	
<p>Supervisory events are shown with a GREEN highlight.</p> <p>The highlighted section gives the time, date and the device type that has caused the supervisory alarm.</p> <p>The table shows more detail of the supervisory event (Address, Device text label, zone, zone text label).</p> <p>The left hand column shows the event number.</p>	
<p>Alarm Verification events are shown with a LILAC highlight.</p> <p>The highlighted section gives the time, date and the device type that has entered alarm verification.</p> <p>The table shows more detail of the alarm verification event (Address, Device text label, zone, zone text label).</p> <p>The left hand column shows the event number.</p>	

When viewing the event log from the engineer menu, there is an option to erase the event log by pressing the




delete icon.

The panel will ask to confirm this action. Press the green tick to continue to delete the log, or cancel to leave the log in the panel.

If the delete is confirmed, the panel will show an indication that it is currently erasing the log.

When viewed from the user menu, there is no delete option.

Note: The event log cannot be erased if there are any events on the system.



Erasing file....

Programming

NOTICE TO USERS, INSTALLERS, AUTHORITIES HAVING JURISDICTION, AND OTHER INVOLVED PARTIES








This product incorporates field-programmable software. In order for the product to comply with the requirements in the Standard for Control Units and Accessories for Fire Alarm Systems, UL 864, certain programming features or options must be limited to specific values or not used at all as indicated below.

Program feature or option	Permitted in UL 864? (Y/N)	Possible settings	Settings permitted in UL 864
ALARM VERIFICATION	Y	ON OFF Retard Time: 1s-30s Confirmation Time: 1-60s	Retard Time: Maximum 30s Confirmation Time: 60s
MULTIPLE DETECTOR OPERATION	Y	Set on two optical detectors	Set on two optical detectors
POSITIVE ALARM SEQUENCE	Y	ON OFF	ON
PRE-SIGNAL	Y	ON OFF	ON OFF
NAC DELAYS	N	0-600s	0s
MAINS RELAY OUTPUT DELAY	Y	0-240 minutes	60-180 minutes
DAY/NIGHT MODE	N	NAC Delay 0-600s Smoke Alarm On/Off Heat Alarm On/Off	NAC Delay 0s Smoke Sensor On Heat Sensor On
BUZZER RESOUND 24H	Y	ON OFF	ON
NAC AUTOMATIC TURN OFF ("Switch off" in C&E effect options)	Y	1-600 seconds	NAC's must operate for a minimum of 180 seconds prior to turn off.

Buzzer Resound 24H Settings

The Velocity has the option to configure whether the panel shall re-sound its internal buzzer every 24 hours. Any alarm, supervisory or trouble events that have been acknowledged but not cleared will resound the buzzer every 24 Hours until they have been cleared from

the panel. To set up the 24H buzzer resound, carry out the following:








<p>Go to the engineer level menu, and select the 'Delays' icon .</p>	
<p>The panel shows the Delays screen.</p> <p>See the 'Resound 24H' section with Off & On options.</p>	
<p>Select ON to enable, or select OFF to keep the 24H buzzer resound disabled.</p> <p>When finished, press the exit icon . The panel will ask if you want to save the changes.</p> <p>Press tick  to save the changes, or press  to discard.</p>	



NOTE: If it is required to have 24 hour buzzer resound across a network of systems, each MMP panel on the network must have the "Resound 24H" option set to ON.

Flash Mute Settings

The Velocity MMP has the ability to control the flasher operation of the panel. The flashers of a notification appliance can be configured to remain flashing after the chimes/horns have been silenced. With this setting, the flashers can only be stopped by pressing the panel reset button to clear the event.

<p>Go to the engineer level menu, and select the 'Delays' icon .</p>		
<p>The panel shows the Delays screen.</p> <p>See the 'Flash Mute' section with Off & On options.</p>		
<p>Select ON to enable, or select OFF to keep the Flash Mute disabled.</p> <p>When finished, press the exit icon . The panel will ask if you want to save the changes.</p> <p>Press tick  to save the changes, or press  to discard.</p>		

Cause and Effect

The Velocity system has very comprehensive, but simple to use Cause and Effect capabilities. The Default factory configuration is that any alarm will activate all outputs on the panel. Like most addressable systems, the panel allows comprehensive programming of the sounders, NAC outputs and relays. It is the responsibility of the commissioning engineer to verify that the programmed panel actions operate the outputs as required. Any input (or cause) can generate any output (or effect). For example, if the input is an Alarm in zone 1 (e.g. an optical detector triggered by smoke), the system can be programmed to generate output(s) (e.g. operate one or more NAC or relay outputs in one or more zones).

The inputs and outputs can be selected from 4 categories – Point, Local I/O, Zone (or alarm group) & Panel.


Example of Selecting a Cause & Effect (New Action):

Press Cause/ Effect icon.

The panel shows the default common cause & effect setting.


1 Cause/effect tabl


DIR (0001)	March on outputs on panel (00)	000	000
1 / 1	Alarm on panel		

If this is not required, tap the action so that it's highlighted yellow, and then press the  icon to delete it.

1 Cause/effect tabl

DIR (0001)	March on outputs on panel (00)	000	000
1 / 1	Alarm on panel		

The screen will indicate that there are no current cause & effects programmed. Press the  button to create a new one.



The panel displays the 'select cause' screen, Choose the cause type (Point, Local I/O, zone or Panel). Depending on the input type chosen, the panel will display a list of sub options. For a '**Point**' cause the options are:-

- Point causes:
 - Alarm
 - Detector Alarm
 - MCP Alarm
 - Trouble
 - Maintenance
 - Supervisory ON
 - Supervisory OFF

- Loop Number:

- 1-26

- Point Address:

- Device Loop Address: 1-254
- Device Port: 0-15 (Select 0 for all ports)

Cause/effect editor
Select cause

☒ Point

☐ Local I/O





☐ Zone

☐ Panel

Point causes : Alarm

Loop number : 1

Point Address : 1

<p>For a 'Local I/O' cause the options are:-</p> <ul style="list-style-type: none"> Local I/O causes: <ul style="list-style-type: none"> Trouble Alarm Supervisory ON Supervisory OFF Local module: <ul style="list-style-type: none"> 1-26 Module Port: <ul style="list-style-type: none"> 1-6 	
<p>For a 'Zone' cause, the options are:-</p> <ul style="list-style-type: none"> Zone causes: <ul style="list-style-type: none"> Alarm Detector Alarm MCP Alarm Trouble Maintenance Supervisory ON Supervisory OFF Mlt. devices in alarm Zone start: <ul style="list-style-type: none"> 1-254 Zone end: <ul style="list-style-type: none"> 1-254 	
<p>For a 'Panel' cause, the options are:-</p> <ul style="list-style-type: none"> Panel causes: <ul style="list-style-type: none"> Alarm Detector Alarm MCP Alarm Trouble Maintenance Supervisory ON Supervisory OFF Mlt. devices in alarm Mlt. zones in alarm Panel Keyswitch ON Panel Keyswitch OFF 	
<p>Select whether this will be an 'AND' cause, an 'OR' cause, or a single 'DIRECT' cause.</p>	

An AND / OR cause will request more inputs before activating the output.

Select up to 8 causes. Press the OUTPUT icon when finished.

AND (0001)	March on Sounders on Panel (00) Retrigger always	000	000
1 / 8	Alarm from zone (001) to (001)		
2 / 8	Alarm from zone (002) to (002)		
3 / 8	Alarm from zone (003) to (003)		
4 / 8	Alarm from zone (004) to (004)		
5 / 8	Alarm from zone (005) to (005)		
6 / 8	Alarm from zone (006) to (006)		
7 / 8	Alarm from zone (007) to (007)		
8 / 8	Alarm from zone (008) to (008)		

After selecting the input cause(s), the panel displays a screen to select the following effect options:

Panel address:

Leave as zero if the output effect is on this local panel, otherwise set to the network address of the destination panel.

Output retrigger:

This defines whether the sounders will resound from a new alarm if they had been previously silenced.

The options are:-

- **Never** resound
- Resound on an alarm from a **New zone**
- **Always** resound for any new alarm.

Cause/effect editor
Effect Options

Panel address : 0

Output retrigger : ☒ Never ☐ New zone ☐ Always

Select the output type (Point, Local I/O, A. Group or Panel). Depending on the OUTPUT type chosen, the panel will display a list of sub options. For 'Point' effects, the options are:-

- Day Delay:
 - 0-600 seconds
- Night Delay:
 - 0-600 seconds

(This is the delay used if Day/Night timer is not set)

- Point Effects:
 - March
 - ANSI-3
 - Continuous
 - Beacon
 - Switch OFF
 - Enable
 - Disable

- Loop number:

- 1-26

- Point address:

- Device Loop Address: 1-254
- Device Port: 0-15 (Select 0 for all ports)

Cause/effect editor
Select effect

☒ Point ☐ Local I/O ☐ A. Group ☐ Panel

Day:Night Dly. : 0 0

Point effects : March

Loop number : 1

Point address : 1 0

For **Local I/O** effects, the options are:-


- Day Delay:
 - 0-600 seconds
- Night Delay:
 - 0-600 seconds

(This is the delay used if Day/Night timer is not set)

- Local I/O effects:
 - March
 - ANSI-3
 - Continuous
 - Switch OFF
 - Enable

- Local module:
 - 1-26

- Module port
 - 1-6



For **A.Group** effects, the options are:-


- Day Delay:
 - 0-600 seconds
- Night Delay:
 - 0-600 seconds

(This is the delay used if Day/Night timer is not set)

- A. Group Effects:
 - March on sounders
 - ANSI-3 on sounders
 - Continuous on sounders
 - Activate Beacon
 - Switch OFF SND/Beacon
 - Switch ON Relays
 - Switch OFF Relays
 - March on Outputs
 - ANSI-3 on outputs
 - Continuous on outputs
 - Switch OFF output
 - Disable sounders
 - Enable sounders
 - Disable relays
 - Enable relays
 - Disable output
 - Enable Output


- A.Group start:
 - 1-254

- A. Group end:
 - 1-254



For a **Panel** effect, the options are:-

- Day Delay:
 - 0-600 seconds
- Night Delay:
 - 0-600 seconds
 (This is the delay used if Day/Night timer is not set)
- Panel Effects:
 - March on sounders
 - ANSI-3 on sounders
 - Continuous on sounders
 - Activate Beacon
 - Switch OFF SND/Beacon
 - Switch ON relays
 - Switch OFF relays
 - March on outputs
 - ANSI-3 on outputs
 - Continuous on outputs
 - Switch OFF output
 - Disable sounders
 - Enable sounders
 - Disable relays
 - Enable relays
 - Disable output
 - Enable output



The panel shows the Programmed cause and effect.

It shows:

First row

- Event type (Direct, AND, OR), and entry number
- The programmed output (effect)
- Day time delay (seconds)
- Night time delay (seconds)

Second row

- Input number & number of inputs (for And & OR statements)
- The programmed input (cause)


1 Cause/effect tabl

DIR (0001)	March on Sounders on panel (00) Retrigger always	030	000
1 / 1	Alarm on panel		

The panel displays direct actions with a red header, AND actions with a blue header, and OR actions with a green header.

3 Cause/effect tabl

DIR (0001)	Continuous on Sounders on panel (00) Retrigger always	030	000
1 / 1	Alarm on panel		
AND (0002)	Continuous on outputs on panel (00) New event retrigger	000	000
1 / 2	Alarm from zone (002) to (002)		
2 / 2	Alarm from zone (003) to (003)		
OR (0003)	Continuous on Sounders on panel (00)	000	000
1 / 3	Detector alarm loop device (01.001.00)		
2 / 3	MCP alarm loop device (01.002.00)		
3 / 3	Trouble loop device (01.003.00)		

It's not possible to edit a cause & effect line. If a line needs to be altered it must be deleted (tap the cause & effect so that it becomes highlighted yellow, and then press the delete icon ). The new statement can now be entered.

3 Cause/effect tabl



DIR (0001)	Continuous on Sounders on panel (00) Retrigger always	030	000
1 / 1	Alarm on panel		
AND (0002)	Continuous on outputs on panel (00) New event retrigger	000	000
1 / 2	Alarm from zone (002) to (002)		
2 / 2	Alarm from zone (003) to (003)		
OR (0003)	Continuous on Sounders on panel (00)	000	000
1 / 3	Detector alarm loop device (01.001.00)		
2 / 3	MCP alarm loop device (01.002.00)		
3 / 3	Trouble loop device (01.003.00)		


Outputs and Delays

Following the indication of a fire, the panel will activate outputs (i.e. NACs and/or relays) according to the cause and effect rules that have been programmed. In certain circumstances, the activation of outputs may be delayed whilst the alarm is being investigated.

NAC Delays

If the operation of NACs has been delayed in one or more of the programmed ACTIONS, then this will be indicated by the illumination of the **NAC DELAY LED**.

During a fire alarm it is possible to override all the NAC delays (at any access level) by pressing the delay override icon  at the bottom of the screen, as shown. When a delay has been overridden, the icon will change to .



NAC Time Limit Cut Out

If required, it is possible to turn of the NAC outputs after a certain period of time. To achieve this, add an extra line of cause and effect that turns off the NACs

<p>▪ Select Panel , Alarm</p>	
<p>Select 'DIRECT' cause.</p>	

<div> <ul style="list-style-type: none"> Select Always retrigger for any new alarm. </div>	<div> </div>
<div> <ul style="list-style-type: none"> Select Panel / Sounder & Beacon Off Set the day and Night timer to the required duration. EG 600 seconds means the NACs will turn off 10 minutes after the alarm was received. </div>	<div> </div>








SLC & Local/IO Relay Output Delays

Relay outputs can also be delayed via the cause and effect actions. In this case, no LED is lit to indicate a delay (since this type of output is not mandatory).

Mains Trouble Relay Output Delay

In the event of a mains power failure, the Velocity can be programmed to delay its TRM trouble relay for a time of between 0-240 minutes. This is normally used when operators do not require momentary mains power failures to send trouble notifications to monitoring stations.

<div> <p>Go to the engineer menu, and select the Delays Icon</p> </div>	<div> </div>
<div> <p>The panel shows the Delays screen.</p> <p>See the ‘Main Delayed’ with the number input field.</p> </div>	<div> </div>



<p>Enter the required mains relay delay time using the onscreen number pad. The time entered is in MINUTES.</p> <p>Press tick  to save the changes, or press  to discard.</p>	
<p>When finished, press the exit icon . The panel will ask if you want to save the changes.</p> <p>Press tick  to save the changes, or press  to discard.</p>	

Programming Delays

Delays to relays and/or NACs can be programmed as part of the cause and effect programming (See previous section). If the delay will be permanently set, the delay should be entered into the NIGHT time delay field. If the delay is only to be set at certain times of the day, the panel should be configured for day/night mode. See the following DAY/NIGHT section for more details.

Switching Off Delays at Access Level 2

The panel allows any programmed delays to be turned off by the user, as this may be required as part of the normal operation of the panel.

<p>Enter the user menu in the usual way. (This option is also available in the Access level 3 Engineer menu)</p>	
<p>The panel shows 'Delay Cancelled' with Off & On options.</p> <p>Select ON to cancel the delay, or select OFF to keep the delay.</p> <p>Press Exit icon and save changes as prompted.</p>	



NOTE: As the delays can be toggled on & off via the user menu. If the delay is not working as expected, check in the user menu if the delays have been turned off.

Day/Night Mode







The Velocity panel has a day night timer that allows certain system responses to be altered at certain times of the day. It allows for different delays for the day and night times, and it also allows the sensitivity of certain detectors to be set differently for the day and night.





NOTE: The default state of the panel is with no day/night settings programmed. It will use the “night time” delays, and the night time detector sensitivity settings.


Defining Day and Night Times



To allow for maximum flexibility, the panel allows for more than one Day-time period each day. For example, if a site closes for a 2 hour break, the panel could be configured with 2 day-time periods e.g. 8:00 – 12:00 and 14:00 – 18:00. Because of this, the panel refers to each setting as a day-time slice.


<p>Enter the engineer menu</p>	
<p>Select the Day/Night Menu icon </p> <p>The panel shows that there are no daytime slices set.</p> <p>Press the add icon  to add a slice.</p>	
<p>Select the day of the week, the start of the day slice and the end of the day slice.</p> <p>Press the tick  to accept.</p>	


The screen shows the programmed day slice(s).


Press the add icon  to add a slice, or press exit icon  if all slices are entered.





When there are more than 4 slices programmed, the panel displays up  /down  scroll arrows in order to view the other slices.






To edit a slice, tap that slice so that it is highlighted yellow, and then press the delete icon .

Press the add icon  to add a replacement slice if required.








When finished, press the exit icon . The panel will ask if you want to save the changes.

Press tick  to save the changes, or press  to discard.







Setting Day-Time and Night-Time Delays

The day and night time delays are set through the cause and effect programming.

<p>Enter the required cause (as described in the Cause and Effect section).</p>																																					
<p>When the panel asks for the output effect, enter the day time delay in the first delay field. The delay is entered in seconds. The maximum delay is 600 seconds (10 minutes).</p> <p>If no night time delay is needed, set the night time delay to Zero in the second field.</p> <p>Setting NOT permitted in UL 864</p>																																					
<p>If a night time delay is needed (e.g. to allow security staff to investigate an alarm), a delay can be entered into the night time delay field.</p>																																					
<p>Press the tick  to save the changes. The panel shows the cause & effect table, with the daytime delay & night time delays shown in the last 2 columns.</p>	 <table><tr><th>DIR (0001)</th><th>ANSI-3 on Sounders on panel (00) Retrigger always</th><th>600</th><th>060</th></tr><tr><td>1 / 1</td><td>Alarm on panel</td><td></td><td></td></tr><tr><td></td><td></td><td></td><td></td></tr><tr><td></td><td></td><td></td><td></td></tr><tr><td></td><td></td><td></td><td></td></tr><tr><td></td><td></td><td></td><td></td></tr><tr><td></td><td></td><td></td><td></td></tr><tr><td></td><td></td><td></td><td></td></tr><tr><td></td><td></td><td></td><td></td></tr></table>	DIR (0001)	ANSI-3 on Sounders on panel (00) Retrigger always	600	060	1 / 1	Alarm on panel																														
DIR (0001)	ANSI-3 on Sounders on panel (00) Retrigger always	600	060																																		
1 / 1	Alarm on panel																																				

Setting Day-Time and Night-Time Detector Sensitivity

The day and night time detector sensitivities are set through the Device options screen.

<p>Go to the engineer menu, and select the “Devices” icon.</p>																										
<p>Select the Option tab. The panel displays the Options table. Press the Options field of the device to be edited.</p> <p>Note that only the following detectors can have their sensitivity altered:-</p> <p>VDOT-PY: Addr Photoelectric Smoke Detector (6th Ed) VDOT-PY3: Addr Photoelectric Smoke Detector (7th Ed) VDOT-PYH: Addr Multisensory Detector (6th Ed) VDOT-PYH3: Addr Multisensory Detector (7th Ed)</p>	 <table><thead><tr><th>Addr</th><th>Type</th><th>Point text</th><th>Mode</th><th>Zone</th></tr></thead><tbody><tr><td>1</td><td>DIP-SCI</td><td>Main Entrance</td><td>Enabled</td><td>1</td></tr><tr><td>2</td><td>PY</td><td>Reception</td><td>Enabled</td><td>1</td></tr><tr><td>3</td><td>DPH</td><td>Canteen</td><td>Enabled</td><td>1</td></tr><tr><td>4</td><td>DOP-SCI</td><td>Admin Hall</td><td>Enabled</td><td>1</td></tr></tbody></table>	Addr	Type	Point text	Mode	Zone	1	DIP-SCI	Main Entrance	Enabled	1	2	PY	Reception	Enabled	1	3	DPH	Canteen	Enabled	1	4	DOP-SCI	Admin Hall	Enabled	1
Addr	Type	Point text	Mode	Zone																						
1	DIP-SCI	Main Entrance	Enabled	1																						
2	PY	Reception	Enabled	1																						
3	DPH	Canteen	Enabled	1																						
4	DOP-SCI	Admin Hall	Enabled	1																						
<p>For the VDOT-PY & VDOT-PY3 (Addressable Photoelectric Smoke Detector), the sensitivity can be set to Low, Normal or High.</p> <p>There can be different settings for day-time & night-time.</p>																										
<p>For the VDOT-PYH & VDOT-PYH3 (Addressable Multisensory Detector), there are settings for the smoke sensor, and for the heat sensor.</p> <p>The smoke sensor can be set to Off, Low, Normal or High (<i>Note: setting to off will make the detector work as a heat detector only</i>).</p> <p>The heat sensor can be set to Off or ON. (<i>Note: setting to off will make the detector work as a smoke detector only</i>).</p> <p>(Note: Setting both sensors to Off will turn off the detector, so it will no longer report an alarm)</p> <p>Setting NOT permitted in UL 864</p>																										


For the VDOT-DPH & there are settings for the smoke sensor, and for the heat sensor.

The smoke sensor can be set to Off or On (*Note: setting to off will make the detector work as a heat detector only*).

The heat sensor can be set to Off or ON. (*Note: setting to off will make the detector work as a smoke detector only*).



(Note: Setting both sensors to Off will turn off the detector, so it will no longer report an alarm)

Setting NOT permitted in UL 864



Indication of Day/Night Mode

The panel indicates its current operating mode by means of a circle in the top left corner of the LCD.

<p>No Day / Night timer set.</p> <p>No circle in top left corner.</p>		
<p>Day / Night timer set. Panel in Day Mode.</p> <p>White circle in top left corner.</p>		
<p>Day / Night timer set. Panel in Night Mode.</p> <p>Black bar in top left corner.</p>		

Alarm Verification

The panel is equipped with an Alarm verification feature that is used to reduce unwanted false alarms. If alarm verification is selected, an addressable smoke detector's alarm is ignored for a retard time of up to 30 seconds and then the detector's alarm condition is automatically reset. There will be no alarm indication at the Velocity MMP panel during the Retard period, only an indication that an alarm is being verified. A confirmation period that is configurable of a time between 1-60 seconds follows, during which a subsequent alarm from the same detector will cause the panel to immediately activate the appropriate outputs and indicate the alarm condition at the panel. If a different detector alarms any time during the first detector's verification period, the panel will immediately activate all appropriate outputs and indicate the alarm condition. If no additional detector alarms occur within 90 seconds of the first alarm (30 second Retard plus 60 second Confirmation), the timer resets and the panel is ready to verify any new detector alarms which may occur.


Alarm verification on the Velocity MMP panel is accomplished on a system wide basis.

Local indication of Verification

If a local indication of the verification is required, a base sounder (VDOT-SB) can be used. The sounder base should be configured to be the next address after the detector.

E.g. the smoke detector at address 83 sees smoke and starts the verification. If there is a sounder base at address 84, it will operate during the verification

Alarm verification timing diagram











NOTE: Alarm Verification is available only for addressable smoke detectors. It cannot be used with addressable heat detectors, or any conventional detectors.

Alarm Verification Setup

Alarm verification can be set up as follows:



<p>Go to the engineer menu, and select the Delays Icon</p>	
--	--

<p>The panel shows the Delays screen.</p> <p>See the 'Alarm Verify' with Off & On options.</p> <p>Select ON to enable, or select OFF to keep the verification disabled.</p>		
<p>The 'Retard Time' is the duration that the alarm signal is initially delayed and can be configured between 1-30 seconds.</p> <p>To change the time, press either the + or – button to increase or decrease the zone number.</p> <p>You can also type in the number via the panel numerical keyboard, to do this press on the zone number field. Type in the required zone number and press the green tick to confirm.</p>		
<p>The 'Period Time' is the confirmation time after the delay (retard) and can be configured between 1-60 seconds.</p> <p>To change the time, press either the + or – button to increase or decrease the zone number.</p> <p>You can also type in the number via the panel numerical keyboard, to do this press on the zone number field. Type in the required zone number and press the green tick to confirm.</p>		
<p>When finished, press the exit icon . The panel will ask if you want to save the changes.</p> <p>Press tick  to save the changes, or press  to discard.</p>		
<p>When a smoke detector has entered the alarm verification sequence, the panel will display an onscreen message to indicate that an alarm is currently being verified accompanied with a zone and device address.</p> <p>At the same time, the smoke detector that is currently in the alarm verification sequence will light up its alarm LED's while it is in the RETARD phase.</p> <p>The panel will record this verification event and store it in the event log.</p>		

When the detector is in the confirmation phase (period time), the detector alarm LED's will turn off and the panel will begin processing if the same detector is still in an alarm state.

If the detector is still in the alarm state, the panel will enter the ALARM condition.

If the detector is no longer in the alarm state, the panel will clear the alarm verification screen and return to quiescent (normal) condition.

<div>  <div> <div>1 Zones in fire</div> <div>1 Devices in fire</div> </div> </div>		
<div>First Alarm</div> <div>Z001 – ZONE 1</div>		
<div>Last Alarm</div> <div>Z001 – ZONE 1</div>		
001	<div>2018/06/20 10:22 --> ALARM – DPH – (01)</div>	
	<div>Point : 002 – 1 – LOOP DEVICE 2</div> <div>Zone : 001 – ZONE 1</div>	
<div></div>		



NOTE: *In a networked system, any verification settings applied to one panel will be applied to all the panels on the network.*

The alarm verification onscreen message will show on all networked panels set to show global events

Multiple Detector Operation

The panel is equipped to satisfy those who require a Multiple Detector Operation feature that is used to reduce unwanted false alarms. If a multiple detector operation has been programmed, the panel will require the activation to two automatic detection devices before it will enter the alarm condition. If a manual detection device is activated, then the panel will immediately enter the alarm condition.








NOTE: Multiple detector operation should not be used with detectors that are also using the Alarm Verification feature.











NOTE: Multiple detector operation should only be used on automatic addressable devices.

Multiple Detector Operation Setup

Multiple detector operation can be set up as follows:

<p>Go to the engineer menu, and select the 'Cause/Effect' icon.</p>		
<p>The cause and effect table screen will be shown. Press the  button to create a new cause and effect.</p>		
<p>The panel displays the 'select cause' screen; choose the cause type (Zone or Panel). A list of sub options will be displayed. For a multi detector operation, select the cause 'Mlt. devices in alarm'.</p>		
<p>Select the 'DIRECT' cause icon.</p>		

<p>After selecting the input cause, the panel displays a screen to select the following effect options:</p> <p><u>Panel address:</u> Leave as zero if the output effect is on this local panel, otherwise set to the network address of the destination panel.</p> <p><u>Output retrigger:</u> This defines whether the sounders will resound from a new alarm if they had been previously silenced.</p>	
<p>Select the output type (Point, Local I/O, zone or Panel). Depending on the OUTPUT type chosen, the panel will display a list of sub options. For more information on output options see the Cause & effect section of this manual.</p> <p>For this example we will select 'Panel (March on Sounders)' as the effect.</p> <p>Press the  to confirm the selections.</p>	
<p>The panel shows the Programmed cause and effect.</p> <p>It shows:</p> <p>First row</p> <ul style="list-style-type: none"> Event type (Direct, AND, OR), and entry number The programmed output (effect) Day time delay (seconds) Night time delay (seconds) <p>Second row</p> <ul style="list-style-type: none"> Input number & number of inputs (for And & OR statements) <p>The programmed input (cause)</p>	
<p>When finished, press the exit icon . The panel will ask if you want to save the changes.</p> <p>Press tick  to save the changes, or press  to discard.</p> <p>Multiple detector operation will now be programmed, and ready for testing.</p>	

When using multiple detector operation in an area, the system design should allow for a minimum of two detectors in that area.

NFPA 72 requires that the spacing of those detectors is reduced to 0.7 times the usual detector spacing to help prevent unnecessarily long alarm response times.

NOTE: When using multi-detector operation, it may be beneficial to add a “backstop Cause and effect” that will operate the sounders after a delay if no second alarm is reported and the panel is not reset.

Positive Alarm Sequence




The Velocity MMP is equipped with a positive alarm sequence that will program a delay to the NAC's, Alarm relays and Auxiliaries for a period of between **1-15 seconds**. If the alarm is acknowledged, it will silence the piezo sounder and start a timer which will prevent activation of these outputs for an additional time duration which can be user programmed between **1-180 seconds**. After the programmed delay, if the source of the alarm is not cleared, all the outputs will activate. If the alarm is not acknowledged or reset during the first time delay of 15 seconds, all the appropriate outputs will be activated. If a second alarm occurs during either time delays, or if a manual alarm is activated, this will immediately cause the activation of the appropriate outputs.



NOTE: Positive alarm sequence can only be used for alarm signals from automatic smoke detection devices.

Positive Alarm Sequence Setup


Positive alarm sequence can be set up as follows:


<p>Go to the engineer menu, and select the Delays Icon</p>		
<p>The panel shows the Delays screen.</p> <p>See the 'Pos Alm Seq' with Off & On options.</p> <p>Select ON to enable, or select OFF to keep the alarm sequence disabled.</p>		
<p>The 'Ack. Time' is the duration of the first time delay and can be configured between 1-15 seconds.</p> <p>To change the time, press either the + or – button to increase or decrease the delay time.</p> <p>You can also type in the number via the panel numerical keyboard, to do this press on the zone number field. Type in the required zone number and press the green tick to confirm.</p>		



The 'Ext. Time' is the duration of the second time delay and can be configured between 1-180 seconds.


To change the time, press either the + or – button to increase or decrease the zone number.

You can also type in the number via the panel numerical keyboard, to do this press on the zone number field. Type in the required zone number and press the green tick to confirm.




When finished, press the exit icon . The panel will ask if you want to save the changes.


Press tick  to save the changes, or press  to discard.




When an alarm from an automatic device is received, the first delay timer will start. The alarm will need to be acknowledged in order to start the secondary delay timer. An acknowledged alarm event will change from flashing red to a solid white colour.


If the alarm is not acknowledged or reset during the first time delay of 15 seconds, all the appropriate outputs will be activated

If the delay needs to be overridden, then press the  icon to cancel the delay and immediately activate the programmed outputs.



During the secondary delay timer, if the alarm is not reset during the time delay of 180 seconds, all the appropriate outputs will be activated.

If the delay needs to be overridden, then press the  icon to cancel the delay and immediately activate the programmed outputs.



A second alarm indication during any of the delays, or if a manual alarm is activated, will immediately cause the activation of the appropriate outputs.

Pre-Signal





The panel is equipped with a means of setting up a Pre-signal where the operation of an automatic detector or initial operation of manual station will only activate selected devices for the purpose of notifying key personnel who then have the option of initiating a general alarm. Any subsequent actuation of an alarm initiating device from a different zone on the system will result in the activation of a general alarm.



NOTE: *PRE-SIGNAL shall only be used when the panel is constantly monitored by an Operator.*

Pre-Signal Setup

Below is just an example of how pre-signal can be achieved on a Velocity MMP system. Ensure that when pre-alarm operation is used, that it complies with UL864 10th Edition requirements.

<p>Go to the engineer menu, and select the 'Cause/Effect' icon.</p>																																					
<p>The cause and effect table screen will be shown.</p> <p>Press the  button to create a new cause and effect.</p>																																					
<p>The first cause and effect that will need to be programmed is to turn on a NAC appliance that will notify key personnel during any alarm signal (normally located in the same room as the panel).</p> <p>For this example we will use a VDOT-SB (Addressable Sounder base) at address Loop:1 Point:1</p> <p>For more information on how to add cause and effects, refer to the Cause and Effect Section.</p>	 <table><tr><td colspan="4">1 Cause/effect tabl</td></tr><tr><td>DIR (0001)</td><td>ANSI-3 on loop device (00.01.001.00)</td><td>000</td><td>000</td></tr><tr><td>1 / 1</td><td>Alarm on panel</td><td></td><td></td></tr><tr><td></td><td></td><td></td><td></td></tr><tr><td></td><td></td><td></td><td></td></tr><tr><td></td><td></td><td></td><td></td></tr><tr><td></td><td></td><td></td><td></td></tr><tr><td></td><td></td><td></td><td></td></tr><tr><td></td><td></td><td></td><td></td></tr></table>	1 Cause/effect tabl				DIR (0001)	ANSI-3 on loop device (00.01.001.00)	000	000	1 / 1	Alarm on panel																										
1 Cause/effect tabl																																					
DIR (0001)	ANSI-3 on loop device (00.01.001.00)	000	000																																		
1 / 1	Alarm on panel																																				

<p>Next, we will add a cause and effect that will ensure that a subsequent activation of alarm initiating devices on another initiating zone of the system shall result in the activation of all the outputs.</p>	<div><div>2 Cause/effect tabl</div><table><tr><td>DIR (0001)</td><td>ANSI-3 on loop device (00.01.001.00)</td><td>000</td><td>000</td></tr><tr><td>1 / 1</td><td>Alarm on panel</td><td></td><td></td></tr><tr><td>DIR (0002)</td><td>March on outputs on panel (00)</td><td>000</td><td>000</td></tr><tr><td>1 / 1</td><td>Mlt. zones in alarm on panel</td><td></td><td></td></tr><tr><td></td><td></td><td></td><td></td></tr><tr><td></td><td></td><td></td><td></td></tr><tr><td></td><td></td><td></td><td></td></tr><tr><td></td><td></td><td></td><td></td></tr></table><div><div></div><div></div><div></div><div></div></div></div>	DIR (0001)	ANSI-3 on loop device (00.01.001.00)	000	000	1 / 1	Alarm on panel			DIR (0002)	March on outputs on panel (00)	000	000	1 / 1	Mlt. zones in alarm on panel																		
DIR (0001)	ANSI-3 on loop device (00.01.001.00)	000	000																														
1 / 1	Alarm on panel																																
DIR (0002)	March on outputs on panel (00)	000	000																														
1 / 1	Mlt. zones in alarm on panel																																
<p>Finally, in this example we will use a key switch connected to a VDOT-DIP-SCI (<i>Addressable Dual Input Module with SCI</i>) at address Loop: 1 Point 2, to allow manual activation of the general alarm evacuation signal.</p>	<div><div>3 Cause/effect tabl</div><table><tr><td>DIR (0001)</td><td>ANSI-3 on loop device (00.01.001.00)</td><td>000</td><td>000</td></tr><tr><td>1 / 1</td><td>Alarm on panel</td><td></td><td></td></tr><tr><td>DIR (0002)</td><td>March on outputs on panel (00)</td><td>000</td><td>000</td></tr><tr><td>1 / 1</td><td>Mlt. zones in alarm on panel</td><td></td><td></td></tr><tr><td>DIR (0003)</td><td>March on outputs on panel (00)</td><td></td><td></td></tr><tr><td>1 / 1</td><td>Alarm on loop device (01.02.00)</td><td></td><td></td></tr><tr><td></td><td></td><td></td><td></td></tr><tr><td></td><td></td><td></td><td></td></tr></table><div><div></div><div></div><div></div><div></div></div></div>	DIR (0001)	ANSI-3 on loop device (00.01.001.00)	000	000	1 / 1	Alarm on panel			DIR (0002)	March on outputs on panel (00)	000	000	1 / 1	Mlt. zones in alarm on panel			DIR (0003)	March on outputs on panel (00)			1 / 1	Alarm on loop device (01.02.00)										
DIR (0001)	ANSI-3 on loop device (00.01.001.00)	000	000																														
1 / 1	Alarm on panel																																
DIR (0002)	March on outputs on panel (00)	000	000																														
1 / 1	Mlt. zones in alarm on panel																																
DIR (0003)	March on outputs on panel (00)																																
1 / 1	Alarm on loop device (01.02.00)																																
<p>This flow chart is a breakdown of the pre-signal operation that has been programmed into the Velocity MMP cause & effects.</p>	<div><div>1st Alarm Signal</div><div><div>Key switch activated by personnel</div><div>Sounder in control room activated</div><div>2nd Alarm Signal from another initiating zone</div></div><div><div>Evacuation on outputs on panel</div><div>Evacuation on outputs on panel</div></div></div>																																
<p>When finished, press the exit icon . The panel will ask if you want to save the changes.</p> <p>Press tick to save the changes, or press to discard.</p> <p>Multiple detector operation will now be programmed, and ready for testing.</p>	<div><div>3 Cause/effect tabl</div><div><div>Confirm the changes?</div><div><div></div><div></div></div></div></div>																																

Disabling

To aid commissioning and assist routine maintenance checks, various functions of the Velocity fire alarm system can be disabled. The Velocity allows disabling of Inputs in a zone, Outputs in an alarm group, individual devices and individual module ports.

Zone Disabling

The following options can be selected when disabling a zone:












Disabled = the input devices in the zone **will not** trigger an alarm, supervisory, or trouble signal.

Enabled = the input devices in the zone **will** trigger an alarm, supervisory, or trouble signal.

This might be used if the system requires routine maintenance, and the user needs the rest of the system to continue running, but doesn't want spurious false alarms.

The panel will respond in the usual manner to any events in any non-disabled zones. Any number of zones can be disabled, but it is good practice to only disable one zone at a time.

A zone can be disabled as follows:

<p>Enter the Engineer or User Password, Press the menu access icon .</p> <p>Select the zone icon  (The disabling function is available to engineer & users).</p> <p>The panel shows the Zone menu.</p> <p>To change the disablement options, press the “In” field.</p>	 <table><thead><tr><th></th><th>Text</th><th>Devices</th><th>In</th></tr></thead><tbody><tr><td>1</td><td>Basement</td><td>14</td><td>Edit</td></tr><tr><td>2</td><td>Reception</td><td>13</td><td>Edit</td></tr><tr><td>3</td><td>Office</td><td>17</td><td>Edit</td></tr><tr><td>4</td><td>Storage</td><td>6</td><td>Edit</td></tr><tr><td>5</td><td>Kitchen</td><td>7</td><td>Edit</td></tr></tbody></table>		Text	Devices	In	1	Basement	14	Edit	2	Reception	13	Edit	3	Office	17	Edit	4	Storage	6	Edit	5	Kitchen	7	Edit
	Text	Devices	In																						
1	Basement	14	Edit																						
2	Reception	13	Edit																						
3	Office	17	Edit																						
4	Storage	6	Edit																						
5	Kitchen	7	Edit																						
<p>This will display the zone options menu.</p> <p>Change the Zone mode to ‘Disable’ by pressing on the selection circle.</p> <p>The  and  icons can be used to scroll to other zone numbers. When finished press the exit icon .</p>																									
<p>The panel will return to the Zone Explorer menu.</p> <p>Select more zones to disable, or if finished, press the exit icon . The panel will ask if you want to save the changes.</p> <p>Press tick  to save the changes, or press  to discard.</p>																									

When zones have been disabled, the LCD display changes from SYSTEM NORMAL to Disablement/Test. The screen shows:-

The number of zones disabled.


The number of zones with just their inputs disabled.


The total number of disabled devices in those zones.


The number of module inputs/outputs disabled.


The General Disablement LED will be lit and also the zonal disablement LEDs will be lit for any zone that is fully disabled.


(The zonal disablement LEDs only apply to panels that have a ZLX PCB fitted).



Details of the disabled zones can be viewed by pressing the disabled zones icon .




Details of the individual disabled SLC devices can be viewed by pressing the disabled loop devices icon .



To re-enable a zone, use the same procedure, pressing the 'Enabled' selection circle.

Zone Mode Options:-




- Enabled
- Disabled
- Test
- Test + Sounder



SLC Device Disablement


Rather than disable an entire zone, it is often useful to just disable one or more devices or points (detector, call point, interface or sounder) within a zone, especially if they are malfunctioning and likely to cause an unwanted alarm or repeatedly indicate a trouble condition.

NOTE: Disabling any device or circuit will cause the panel to enter the trouble condition. The trouble buzzer, trouble LED's and trouble relays will be activated.


Enter the Engineer  or User password , Press the menu access icon, and select the Point icon .


(The disabling function is available to engineer & users).

The panel shows the Point menu.



Press on the 'Mode' field for the device to be disabled.

Select further devices to disable if necessary, and then press Exit  to save.





When SLC devices have been disabled, the LCD display changes from SYSTEM NORMAL to Disablement/Test, as shown.


The screen shows the number of devices disabled.

The General Disablement LED will be lit, but the zonal disablement LEDs will not light, unless all devices in that zone have been disabled. The panel will also enter the trouble condition.


Note: If an input on a module is in the same zone as loop devices, the loop devices, and the module inputs will need to be disabled before the Zone disabled indication appears.



Details of the individual SLC devices disabled can be viewed by pressing the 'Disabled loop devices' icon .






To re-enable a device, use the same procedure, pressing the 'Mode' field until it shows 'Enabled'.



Once a SLC device is disabled, the panel ignores any alarm or trouble generated by the device. If all devices in a zone are disabled, the panel will indicate a zone disablement. If subsequently one or more devices in that zone are re-enabled then the zone disablement indication will be automatically cancelled. The trouble condition will be automatically cancelled when all disabled circuits/devices are re-enabled.

Alarm Group Disablement

Enter the Engineer or User Password, Press the menu access  icon, and select the Alarm group Icon  (The disabling function is available to engineer & users).
The panel shows the Alarm Group Explorer.



Global Mode Disablement

When Global mode is set to disabled, the panel will not activate any alarm group devices. This might be used if the system requires routine maintenance, and the user needs the rest of the system to continue running, but doesn't want spurious NAC activations. The panel will respond in the usual manner to any events in any non-disabled zones.


NOTE: Disabling any circuit or device will cause the panel to enter the trouble condition. The trouble buzzer, trouble LED's and trouble relays will be activated.



Global mode can be disabled, but it is good practice to only disable one alarm group at a time.


Global mode can be disabled as follows:

Change the global mode for relay status to disabled by pressing the 'Disabled' selection area. The text will change from 'All enabled' to 'All disabled' for relay status.

This will disable **ALL** panel relay output interfaces.

Press the exit icon . The panel will ask if you want to save the changes.


Press tick  to save the changes, or press  to discard.



When global relays have been disabled, the LCD display changes from SYSTEM NORMAL to Disablement, as shown.


The screen shows the number of relay output interfaces disabled.

The General Disablement LED will be lit, and the panel will enter the trouble condition.



Details of the disabled relay outputs can be viewed by pressing the disabled loop devices icon or the disabled local I/O icon .


If any alarm group has all of their outputs disabled, it will be indicated by the 'Disable Alarm Groups' icon .



To re-enable the relay status, press the 'Enabled' selection area. The text will change from 'All disabled' to 'All Enabled' for relay status.

Press the exit icon . The panel will ask if you want to save the changes.

Press tick to save the changes, or press to discard.




Change the global mode for sounder status to disabled by pressing the 'Disabled' selection area. The text will change from 'All enabled' to 'All disabled' for sounder status.

This will disable **ALL** panel NAC output interfaces.

Press the exit icon . The panel will ask if you want to save the changes.

Press tick to save the changes, or press to discard.



When sounder status has been disabled, the LCD display changes from SYSTEM NORMAL to Disablement. The screen shows: -


The number of disabled SLCNAC devices.



The number of disabled NAC outputs.


The General Disablement and NAC Disablement LEDs will be lit. The panel will also enter the trouble condition.


If there are any output relays on the system that are not disabled, the Disabled Alarm Group icon will not be displayed.

If there are no relays in the alarm group, or if the relays have also been disabled, the Disabled Alarm Group icon will be displayed.



Details of the disabled NAC outputs can be viewed by pressing the disabled loop devices icon  or the disabled local I/O icon .




If any alarm groups have all of their outputs disabled, it will be indicated by the 'Disabled Alarm Groups' icon .



10 Disablement

1 Loop number

Address	Type	Point text	Mode
9	SB	Boiler Room	Disabled
21	SB	Reception	Disabled
32	SB	Room A2	Disabled
46	SB	Room B4	Disabled



Alarm Group Mode

When Alarm group mode is disabled, the panel will not activate any output devices on that alarm group (zone). This might be used if the system requires routine maintenance, and the user needs the rest of the system to continue running, but doesn't want spurious output activations. The panel will respond in the usual manner to any events in any non-disabled zones.

Any number of alarm group (zones) can be disabled, but it is good practice to only disable one alarm group/zone at a time.


NOTE: Disabling any circuit or device will cause the panel to enter the trouble condition. The trouble buzzer, trouble LED's and trouble relays will be activated.

An alarm group (zone) can be disabled as follows:

Enter the Engineer or User Password, Press the menu access icon , select the Alarm group Icon  and select the A. Grp Mode tab.

(The disabling function is available to engineer & users).

The panel shows the Alarm Group mode menu.






Alarm Group Explorer

Global Mode

A. Grp Mode


	Text	Out
1	Basement	All enabled
2	Reception	All enabled
3	Office 1	All enabled
4	Office 2	All enabled

Set the alarm group to disabled by pressing the 'Out' field. The status will change from all enabled to Sounder Disabled.

This would disable all sounder (NAC) outputs in that alarm group (zone).

Disable further alarm groups in the same way, or press exit to save.






Alarm Group Explorer

Global Mode


A. Grp Mode

	Text	Out
1	Basement	Sounders disabled
2	Reception	All enabled
3	Office 1	All enabled
4	Office 2	All enabled

For further options, press the 'Out' field again. The status will change from 'Sounder disabled' to 'Relay disabled'.

This would disable all relay outputs in that alarm group (zone).












Alarm Group Explorer

Global Mode

A. Grp Mode

	Text	Out
1	Basement	Relays disabled
2	Reception	All enabled
3	Office 1	All enabled
4	Office 2	All enabled

<p>For further options, press the 'Out' field again. The status will change from 'Relay disabled' to 'All disabled'.</p> <p>This would disable all sounder (NAC) and relay outputs in that alarm group (zone).</p>	<div><div>Alarm Group Explorer</div><div><div>Global Mode</div><div>A. Grp Mode</div></div><table><thead><tr><th></th><th>Text</th><th>Out</th></tr></thead><tbody><tr><td>1</td><td>Basement</td><td>All disabled</td></tr><tr><td>2</td><td>Reception</td><td>All enabled</td></tr><tr><td>3</td><td>Office 1</td><td>All enabled</td></tr><tr><td>4</td><td>Office 2</td><td>All enabled</td></tr></tbody></table><div><div></div><div></div><div></div><div></div></div></div>		Text	Out	1	Basement	All disabled	2	Reception	All enabled	3	Office 1	All enabled	4	Office 2	All enabled													
	Text	Out																											
1	Basement	All disabled																											
2	Reception	All enabled																											
3	Office 1	All enabled																											
4	Office 2	All enabled																											
<p>When the Alarm group mode has been disabled, the LCD display changes from SYSTEM NORMAL to Disablement. The screen shows: -</p> <p>The number of disabled alarm groups.</p> <p>The number of disabled SLC devices.</p> <p>The number of disabled module outputs.</p> <p>The General Disablement and NAC disablement LED will be lit if Sounder disabled or All disabled was selected.</p> <p>Only the General Disablement LED will be lit if just Relay disabled was selected.</p>	<div><div><div>9</div><div>Disablement</div></div><div><div><div>1</div><div></div><div>Disabled Alarm Groups</div></div><div><div>4</div><div>I/O</div><div>Disabled Local I/O</div></div><div><div>4</div><div></div><div>Disabled loop devices</div></div></div><div><div></div><div></div></div></div>																												
<p>Details of the disabled alarm group outputs can be viewed by pressing the disabled loop devices icon  or the disabled local I/O icon . If any alarm groups have all of their outputs disabled, it will be indicated by the 'Disabled Alarm Groups' icon .</p>	<div><div><div>9</div><div>Disablement</div></div><div><div>1</div><div>Loop number</div></div><div><div></div><div></div></div><table><thead><tr><th>Adress</th><th>Type</th><th>Point text</th><th>Mode</th></tr></thead><tbody><tr><td>4</td><td>DOP-SCI</td><td>Boiler Shutoff</td><td>Output Disabled</td></tr><tr><td>5</td><td>SB</td><td>Janitor Office</td><td>Disabled</td></tr><tr><td></td><td></td><td></td><td></td></tr><tr><td></td><td></td><td></td><td></td></tr><tr><td></td><td></td><td></td><td></td></tr><tr><td></td><td></td><td></td><td></td></tr></tbody></table><div><div></div><div></div><div></div><div></div></div></div>	Adress	Type	Point text	Mode	4	DOP-SCI	Boiler Shutoff	Output Disabled	5	SB	Janitor Office	Disabled																
Adress	Type	Point text	Mode																										
4	DOP-SCI	Boiler Shutoff	Output Disabled																										
5	SB	Janitor Office	Disabled																										
<p>To re-enable an alarm group, use the same procedure, pressing the "Out" field until it shows 'All Enabled'.</p> <p>It cycles through: -</p> <ul style="list-style-type: none">All enabledSounder disabledRelay DisabledAll Disabled <p>Press the exit icon . The panel will ask if you want to save the changes.</p> <p>Press tick  to save the changes, or press  to discard.</p>	<div><div>Alarm Group Explorer</div><div><div>Global Mode</div><div>A. Grp Mode</div></div><table><thead><tr><th></th><th>Text</th><th>Out</th></tr></thead><tbody><tr><td>1</td><td>Basement</td><td>All enabled</td></tr><tr><td>2</td><td>Reception</td><td>All enabled</td></tr><tr><td>3</td><td>Office 1</td><td>All enabled</td></tr><tr><td>4</td><td>Office 2</td><td>All enabled</td></tr></tbody></table><div><div></div><div></div><div></div><div></div></div></div>		Text	Out	1	Basement	All enabled	2	Reception	All enabled	3	Office 1	All enabled	4	Office 2	All enabled													
	Text	Out																											
1	Basement	All enabled																											
2	Reception	All enabled																											
3	Office 1	All enabled																											
4	Office 2	All enabled																											

Local I/O (Module) Disablement



When a local I/O is disabled, the panel will not react to any alarm or trouble signal from that local I/O (module).

This might be used if the system requires routine maintenance, and the user needs the rest of the system to continue running, but doesn't want spurious input/output activations.

The panel will respond in the usual manner to any events in any non-disabled parts of the system.

Any number of local I/O's can be disabled, but it is good practice to only disable one at a time.


A local I/O can be disabled as follows:

Enter the Engineer or User Password, Press the menu access icon , select the 'local I/O' icon .

(The disabling function is available to engineer & users).

The panel shows the module selection menu.

Select the required port number. The port number is shown in the brackets on the left. When you select a module, it will become highlighted. The up and down arrows can be used to cycle through pages. Press the green tick to confirm the selection.



MIM/ZMA/ZMB Disablement

The module settings screen will be displayed.




In this example, the input address is shown as: **(3.1)**. The first number represents the TRM port (The RJ45 port on the TRM PCB that the module is plugged into). The second number represents the input on the module itself.



E.g. a ZMA that is plugged into TRM port 3 would have the following addresses:

(3.1) = TRM Port 3, Input 1


(3.2) = TRM Port 3, Input 2

(3.3) = TRM Port 3, Input 3

To disable an input, change the mode by pressing on the 'Disabled' selection circle, then press  or  to cycle through more inputs, or the exit icon . The panel will ask if you want to save the changes.

Press tick  to save the changes, or press  to discard.

(NOTE: When an input has been disabled, the module Short & Trouble LED's will be lit [Yellow constant] to indicate the disablement)



MRM Disablement

(NOTE: A MRM output can only be disabled if the output type is set to 'Programmable')

The module settings screen will be displayed.



In this example, the relay address is shown as: **(1.1)**. The first number represents the TRM port (The RJ45 port on the TRM PCB that the module is plugged into). The second number represents the output on the module itself.


E.g. a MRM that is plugged into TRM port 1 would have the following addresses:


(1.1) = TRM Port 1, Output 1



(1.2) = TRM Port 1, Output 2


(1.3) = TRM Port 1, Output 3

To disable an input, change the mode by pressing on the 'Disabled' selection circle, then press  or  to cycle



through more outputs, or the exit icon . The panel will ask if you want to save the changes.

Press tick  to save the changes, or press  to discard.



NCA/NCB Disablement




The module settings screen will be displayed.



In this example, the output address is shown as: **(2.1)**. The first number represents the TRM port (The RJ45 port on the TRM PCB that the module is plugged into). The second number represents the output on the module itself.


E.g. A NCB that is plugged into TRM port 2 would have the following addresses:

(2.1) = TRM Port 2, Output 1

(2.2) = TRM Port 2, Output 2

To disable an input, change the mode by pressing on the 'Disabled' selection circle, then press  or  to cycle through more inputs, or the exit icon . The panel will ask if you want to save the changes.

Press tick  to save the changes, or press  to discard.






When a module has a disablement, the LCD display changes from SYSTEM NORMAL to Disablement. The screen shows:-


The number of disabled alarm groups.
The number of disabled local I/O.

The General Disablement LED will be lit with any module disablement.

The General Disablement and NAC disablement LED will be lit if a NCA or NCB port is disabled.



Details of the disabled module inputs/outputs can be viewed by pressing the disabled local I/O icon . If any zones have all of their outputs disabled, it will be indicated by the disabled zone outputs icon .



	Text
SOUNDER CLASS	(004.001) – HALLWAY B SOUNDERS
RELAY	(006.001) – DOOR MAGNET HALLWAY B

NOTE: Disabling a circuit will cause the panel to enter the trouble condition. The trouble buzzer, trouble LED's and trouble relays will be activated.

Test Mode

Why Use Test Mode?










To aid commissioning and assist routine maintenance checks, a non-latching 'one man test' facility is available. Test mode can be used either with or without sounder operation, depending on the engineer's requirements.





When a detector, manual call point or input unit is triggered on any zone in Test, the Alarm sounders operate for approximately 3 seconds on and then switch off (If selected). The triggered device is automatically reset. The panel will display the tested device on a test alarm screen, with the event highlighted in blue. The device automatically resets from the fire condition, but the LCD indication remains until the panel is manually reset.


If the device is still in the fire condition, e.g. MCP still activated or the analogue value of a detector still above the alarm threshold, the device will be triggered again and the Alarm sounders will operate again.

Should an Alarm occur on a zone that is not programmed to test, the Fire Alarm Panel will operate as normal and signal an alarm.

To Programme a Zone into Test Mode

<p>Enter the Engineer  or User password  , Press the menu access icon, and select the zone icon  .</p> <p>(The test function is available to engineer & users).</p> <p>The panel shows the zone menu.</p> <p>Select the zone(s) to be placed into test by pressing on the 'In' Field.</p>	 <table><thead><tr><th></th><th>Text</th><th>Devices</th><th>In</th></tr></thead><tbody><tr><td>1</td><td>ZONE 1</td><td>28</td><td>Edit</td></tr><tr><td>2</td><td>ZONE 2</td><td>18</td><td>Edit</td></tr><tr><td>3</td><td>ZONE 3</td><td>11</td><td>Edit</td></tr><tr><td>4</td><td>ZONE 4</td><td>7</td><td>Edit</td></tr><tr><td>5</td><td>ZONE 5</td><td>10</td><td>Edit</td></tr></tbody></table>		Text	Devices	In	1	ZONE 1	28	Edit	2	ZONE 2	18	Edit	3	ZONE 3	11	Edit	4	ZONE 4	7	Edit	5	ZONE 5	10	Edit
	Text	Devices	In																						
1	ZONE 1	28	Edit																						
2	ZONE 2	18	Edit																						
3	ZONE 3	11	Edit																						
4	ZONE 4	7	Edit																						
5	ZONE 5	10	Edit																						
<p>The panel will show the zone options menu.</p> <p>There will be two test modes to choose from:</p> <p><u>Test</u> This will give a silent test, with no sounders operating.</p> <p><u>Test + Sounder</u> This will operate all the sounders in that zone for approximately 10 seconds, regardless of the cause and effect programming.</p> <p>Change the Zone mode to either 'Test' or 'Test + Sounder' by pressing on the selection circle.</p>	 <p>Zone Explorer (1) Zone number </p> <p>Zone Text : ZONE 1</p> <p>Devices : 028</p> <p>Zone mode : <input type="radio"/> Enabled <input type="radio"/> Disabled <input checked="" type="radio"/> Test <input type="radio"/> Test + So</p>																								
<p>When all required zones have been selected, press exit and accept the change. The panel will return to the menu, showing that there is a Disablement or test condition present  .</p>	 <p>Engineer level </p> <p>loop Zone Devices log system Cause/Effect</p> <p>local I/O day/night lcd/led network Delays Alarm Group</p>																								

<p>To view which zones are in test mode, press the zones in test icon .</p>	 <p>The screenshot shows the 'Supervisory/Test' screen. At the top, there is a header with a wrench icon and the text 'Supervisory/Test'. Below the header is a table with columns 'Text' and 'In'. The first row shows 'ZONE 1' in the 'Text' column and 'Test' in the 'In' column. Below the table are two icons: a lock icon and a plus icon.</p>
<p>Proceed to test the devices.</p> <p>As we are checking the devices, the test alarms are reported on the supervisory screen.</p>	 <p>The screenshot shows the 'Supervisory' screen with a yellow warning icon and the text '7 Supervisory'. Below the header is a list of test alarms. Each alarm entry includes a time, a point number, and a zone. For example, the first alarm is '2018/02/10 12:32 --> ALARM-PY-(01)' with point '004 - 1 - LOOP DEVICE 4' and zone '001 - ZONE 1'.</p>
<p>When the testing is complete, take the panel out of test mode by entering the Engineer level menu and selecting the 'zone' icon.</p> <p>Select the zone(s) to be taken out of test by pressing on the 'In' Field.</p> <p>Change the Zone mode to 'Enabled' by pressing on the selection circle.</p> <p>Press exit and save changes in order to return the panel to normal.</p>	 <p>The screenshot shows the 'Zone Explorer' screen. At the top, there is a header with a wrench icon and the text 'Zone Explorer'. Below the header is a form with fields for 'Zone Text' (containing 'ZONE 1') and 'Devices' (containing '028'). Below the form are four radio buttons for 'Zone mode': 'Enabled' (selected), 'Disabled', 'Test', and 'Test + So'. At the bottom are three icons: a left arrow, a down arrow, and an up arrow.</p>

 **NOTE:** Zones that are placed into test mode will be automatically re-enabled after 60 minutes.


Networking

The Velocity requires a VL-NWM module to network to another Velocity system.

Up to 64 control panels (CIEs) can be connected together, i.e. networked. The maximum distance between nodes is 1KM when using a screened data cable, or 100M when using a standard fireproof cable.

The network can be configured with a ring or bus topology, but would recommend the network is wired as a ring for better fault tolerance.

Network Typologies



Ring Network (Class A)

In a ring network, each control panel is connected to 2 other control panels to form a ring. This has the same topology as the loops of addressable devices connected to each CIE. This has the advantage that no panels are lost if there is a single break in the network.













NOTE: It is recommended that you install and wire your network in a ring topology for better stability and redundancy.

Bus Network (Class B)

This is similar to a ring network but wired panel to panel without a return connection from last panel to first panel. It could also be referred to as a radial or spur network.

Configuring the Network

<p>Enter the engineer menu.</p>		
<p>Select the Network options icon .</p> <p>The panel will show the module selection screen, select the correct 'RS485 Network'. The port number is shown in the brackets on the left. When you select the module it will become highlighted. Press the green tick to confirm the selection.</p> <p><i>The port number will be labelled on the TRM PCB inside the panel and are also shown in the Velocity Installation manual (Doc:GLT-261-7-1).</i></p>		
<p>The panel shows that the network connection is disabled (It's default state).</p>		
<p>Press the 'Address' field to edit the velocity panel network address if required (Range 1-64).</p> <p>(NOTE: A velocity network does not allow for duplicate node addresses. Each panel must have a unique address number)</p> <p>Press tick  to save the changes, or press  to discard.</p>		
<p>Press the 'Name' field to edit the velocity panel network text label if required (43 characters max).</p> <p>Press tick  to save the changes, or press  to discard.</p>		

Next, configure the network mode.

Disabled:


The network connection is disabled


Enabled local:

The local panel will not receive alarm and fault messages from remote panels.

Enabled global:

The local panel will receive alarm and fault messages from remote panels.

Press tick  to save the changes.





Network Setup


Mode : ☐ Disabled ☐ Enabled local ☒ Enabled global


Address :

Name :


 

Repeat the above steps for every Velocity panel on the network.

Then press the Add icon  to search and configure the network.



Network Setup




When the search is complete, the panel shows a list of network node addresses seen, and whether the panel sees a connection on Network port A (NET 1), and Network port B (NET 2).

If the panel sees a connection it reports the port as UP. If it does not see a connection, it reports the port as down.

(In this example we have a four panel network)



The icon  can be pressed to rescan the network.



Network Setup

4 Nodes

	Address	Net 1	Net 2
1	1	Up	Up
2	2	Up	Up
3	3	Up	Down
4	4	Down	Up









Running the Network

On a Velocity panel, running in a network, all events are reported at all panels. All panels are able to silence sounders, reset the systems, and acknowledge events across the network when a suitable access code has been entered.

Operation of outputs over the network is determined by the programmed cause & effect. Any input on the network can be programmed to operate any output. The cause & effect is entered at the panel that has the INPUT CAUSE connected.

Configuring the RS232 Panel Printer

The Velocity panel has been designed to report events to a panel printer. This will provide automatic, or on demand copy listings of the event log or status information.

<p>Enter the engineer menu.</p>	
<p>Select the Network options icon .</p> <p>The panel will show the module selection screen, select the correct 'Printer'. The port number is shown in the brackets on the left. When you select the module it will become highlighted. Press the green tick to confirm the selection.</p> <p><i>The port number will be labelled on the TRM PCB inside the panel and are also shown in the Velocity Installation manual (Doc:GLT-261-7-1).</i></p>	
<p>The panel shows the RS232 printer options menu.</p>	
<p>If a panel printer is used, set the Baud Rate to '9600' (as this is the default baud rate of the panel printer).</p> <p>Next, select what real time printing options you want to be enabled, you can choose from:</p> <ul style="list-style-type: none"> Alarm Real-Time Printing Fault Real-Time Printing Tech Alarm Real-Time Printing Button Press Real-Time Printing <p>To enable the options, press on the relevant selection circle.</p> <p>When done, press the exit icon . The panel will ask if you want to save the changes.</p> <p>Press tick  to save the changes, or press  to discard.</p>	

Maintenance

It is recommended that the owner or person having control of the premises should appoint a responsible person to oversee the effective operation of the Fire Alarm System.

VELOCITY control panels do not require any specific maintenance but should the control panel become dirty it can be wiped over with a damp cloth and should then be dried with a dry, lint free cloth. Solvents or detergents should not be used to clean the panel and take care not to allow any water to enter the enclosure.

Below is a summary of the main functions the “Responsible Person” is expected to carry out. This summary is intended to give a brief outline of user responsibilities for the safe upkeep of the Fire Alarm System.

The responsible person must:-

1. Have sufficient authority to carry out the duties associated with being the responsible person
2. Check the system at least once every 24 hours to ensure there are no faults present
3. Ensure there are arrangements for testing and maintaining the system
4. Ensure the log book is up to date, and available for inspection
5. Instruct all relevant occupants on the basic operation of the system, including start evacuation, silence alarms, silence troubles and system reset if applicable.
6. Take appropriate action to limit the rate of false alarms, by reporting events to the company maintaining the system
7. Ensure that all detectors and manual call points remain unobstructed at all times
8. Liaise with maintenance personnel to ensure that cleaning, maintenance or building work does not interfere with the functioning and reliability of the fire alarm system
9. Ensure any changes to the system are recorded with updated drawings, operating instructions etc.
10. Ensure that there are spare parts held on site
11. In the event of a pre-alarm, determine the cause & take appropriate action (predetermined fire routine if the cause is the start of a fire, arrange maintenance if the cause is a contaminated detector head)

With the Velocity MMP Fire Alarm Panel, we recommend the following tests are carried out: -

Daily Inspection

- Check that the green Power LED is lit.
- If there are any yellow trouble LEDs lit, or the green Power LED is not lit, report the troubles(s) to the designated site maintenance engineer.

Weekly Test (you may wish to temporarily disable any relay outputs during the following Tests – See Alarm Group section)

- Set off a manual call point or sensor to test the Fire Alarm panel responds and all the sounders activate.
- Do not test the same device each week. Test a different zone each week using a different call point or detector so that eventually, all the devices will be tested.
- To reset the System, enter access code, then press the Reset button).
- Check that no call points or fire detectors are obstructed in any way. (e.g. New furniture or decorations)

Quarterly Test (to be carried out by authorised service personnel only)

- Check that any servicing or repairs required by all previous logbook entries has been undertaken.

- Visual inspection of the batteries and connections. Check the alarm sounders work on battery only.
- Activate a device from each zone to test the fire alarm. (As per weekly test).
- Enter access code and go to the menu. Press the LED Test icon. Check that all LEDs light and the buzzer sounds.

Annual Test (to be carried out by authorised service personnel only)

- Check every detector, call point, sounder and all auxiliary equipment for correct operation.
- Check Switch Mode cage Voltage (30 VAC), Charger Voltage (27.3V off load, adjusted with VR1) & Battery Voltage (25-27V)
- Check the backup batteries condition with a suitable test meter

Every Five Years (to be carried out by authorised service personnel only)

- Carry out a complete wiring check in accordance with the testing and inspection requirements of the relevant National wiring regulations (in the UK this is the IEE Wiring Regulations). The Batteries should be replaced because SLA batteries have a working life of 5 years.





Should the control panel become defective; some electronic assemblies can be replaced.

To do this, any configured options should be noted and the panel configuration should be downloaded and saved (if available), then both mains and battery power should be removed before the work is started. Internal panel and field wiring should be carefully labelled and removed from the terminals.

The Module or PCB can now be taken out of the panel by removing any securing bolts or nuts.
Fitting the new part is the reverse of the procedure for removing the board





SLC Contents Trouble Finding


If the SLC contents are different to what was expected, then there two probable causes:

DOUBLE ADDRESS / MULTIPLE ANSWER FAULT		<p>The panel has detected two or more devices answering at the same address (each device on the loop should have a unique address)</p> <ul style="list-style-type: none"> • If a device has just been added or replaced, and the system was ok before, check that device has the correct address programmed. • To turn on the LED of the double addressed devices, perform a loop search, view the detailed tab, then tap on the address showing double address. Walk around the site to find the devices with their LEDs on (Note: will not work on devices with no LEDs, such as Mini-IP, and Sounder base) • Try removing the known device for that address, and perform a loop search. The detail screen should indicate what type of device is now seen at that address, which should help reduce the search • If a new installation, check the site plans, and compare with empty addresses seen on that loop
DEVICE NOT RESPONDING		<p>Check if that device has been removed</p> <p>Check for any cable breaks to that device</p> <p>Check that the devices address has not been changed</p> <p>Try a replacement device</p>
CHANGED TYPE		<p>The panel has seen that the device type fitted to an address is different to its last saved configuration.</p> <p>Replace the device with the correct type of device</p> <p>If the change was deliberate, relearn the loop.</p>
SENSOR FAULT		<p>A device has detected an internal fault, and should be replaced</p>
MAINTENANCE WARNING		<p>A device (usually a smoke detector) has reached the end of its drift compensation</p>

Devices not seen on a loop search		<p>Check that the wiring polarity to the device is correct.</p> <p>Check that the device has the correct address</p> <p>Check that the device is compatible with the MMP panel</p>
-----------------------------------	--	--

Power Supply Trouble


MAINS SUPPLY FAULT		<p>Carefully check that you have mains voltage at the fused terminal block</p> <p>Check that the mains fuse is intact</p> <p>If mains & fuse are OK, Check that the PSU cage is giving out 30V DC (will need charger cover to be removed to check. Only attempt this if suitably trained)</p> <p>Check PSU Status LED's.</p>
BATTERY REMOVED		<p>Check battery fuse (Fuse E).</p> <p>Check that battery connections are secure.</p> <p>Check battery voltage (should be around 26-27V for well charged batteries).</p> <p>Check that 2 x 12V VRLA batteries are connected in series to give 24V</p> <p>Check the date on the batteries and replace if necessary. (Batteries normally have to be replaced every 4-5 years).</p>
BATTERY CHARGER FAULT		<p>The panel has determined that the power supply is not charging the batteries.</p> <p>Try power cycling the panel.</p> <p>If the fault returns within 30 minutes, it is likely to be a problem with the Charger PCB. Contact your supplier to arrange a replacement charger PCB</p>
BATTERY HIGH IMPEDANCE FAULT		<p>Battery internal resistance check. Usually disabled on a UL system.</p> <p>Check battery condition of both batteries with a battery load test meter</p> <p>Check that all connections to batteries are tight.</p> <p>Check that batteries are less than 5 years old.</p> <p>Replace batteries if necessary.</p>

24V OUTPUT FAULT (X)	 <div>1 Troubles</div> <div>001 2018/10/04 16:22 --> POWER SUPPLY FAULT</div> <div>24V OUTPUT FAULT C</div>	<p>The panel has detected a problem with one of the PSU output fuses</p> <p>Fuse A&B are auxiliary fuses</p> <p>Fuse C&D are used to power the panel</p> <p>Check the fuse in the reported output and replace if necessary.</p>

Earth Trouble

An EARTH fault indicates that something is shorting to earth (usually through the cable screen). Disconnect the earth screens one at a time to determine the problem line. (Note: connecting other equipment, e.g. a mains powered laptop, to the panel can give an earth fault)


The earth fault message will indicate if voltage is shorting to earth.

EARTH FAULT	 <div>1 Troubles</div> <div>001 2018/06/19 02:49 --> EARTH FAULT</div> <div>EARTH FAULT</div>	<p>Most Earth faults occur on the field wiring. As a first check, disconnect field wiring from the Velocity Panel. If no earth fault is reported then fault is on the field wiring. Locate the fault by reconnecting one field wiring circuit at a time until the earth fault reports, then sub divide the “bad circuit”. Look for a cable screen shorting to either +vet or –vet.</p>

CPU Trouble


A CPU fault is an abnormal microprocessor running condition due to various unexpected phenomena.

This will result in the panel attempting to correct itself. Should this fault occur, the CPU Trouble LED, Common Trouble LED, Common Trouble relays and internal Trouble buzzer will be constantly active. A CPU trouble indication can be cleared by pressing the CPU reset button located on the TRM PCB. If the trouble condition does not clear please consult your distributor.



Appendix A: User Menu Summary

Default Password 0001 (User 1) – Access level 2b




Icon	Tab Screen	Description
Zone	Zone Explorer	View Zone text label View Quantity of devices per zone
	Zone Edit	View Zone text label View Quantity of devices per zone View/Edit zone mode (Enabled/Disabled/Test/Test+Sounder)
Point	Basic	View Address & Device type View Device text label View/Edit device mode (Enabled/disabled) View Device Zone allocation
	Real Time	View Address & Device type View Device text label View device Analogue Values
Log	-	View Event Log
Local I/O	Zone Class A	View input (1-3) text label View input (1-3) zone allocation View input (1-3) type (Alarm/Supervisory) View/Edit input (1-3) status (Disabled/Enabled)
	Zone Class B	View input (1-6) text label View input (1-6) zone allocation View input (1-6) type (Alarm/Supervisory) View/Edit input (1-6) status (Disabled/Enabled)
	Input Class B	View input (1-3) text label View input (1-3) zone allocation View input (1-3) type (Alarm/Supervisory) View/Edit input (1-3) status (Disabled/Enabled)
	Relay	View output (1-3) text label View output (1-3) zone allocation View output (1-3) type (Alarm/Trouble/Supervisory/Programmable) View/Edit output (1-3) mode (Disabled/Enabled)
	Sounder Class A	View output (1) text label View output (1) zone allocation View output (1) type (Sounder/Bell/Voltage)

		View/Edit output (1) mode (Disabled/Enabled)
	Sounder Class B	View output (1-2) text label View output (1-2) zone allocation View output (1-2) type (Sounder/Bell/Voltage) View/Edit output (1-2) mode (Disabled/Enabled)
LCD/LED	-	Test panel LEDs, LCD & Buzzer
Delays	-	Toggle panel delays on or off
Alarm Group	Global Mode	View/Edit Relay Status (Disabled/Enabled) View/Edit Sounder Status (Disabled/Enabled)
	A. Grp Mode	View text label View/Edit A. Grp mode (All enabled/Sounder disabled/Relay disabled/All disabled)

Appendix B: Engineer Menu Summary

Default Password 9999 – Access level 3



Icon	Tab Screen	Description
Loop	Module Selection	Select Loop Module to automatically search for all devices on the loop.
	Summary	Summary of all devices found on loop
	Detail	Detailed view of all devices found on loop
Zone	Zone Explorer	View Zone text label View Quantity of devices per zone
	Zone Edit	View/Edit Zone text label View quantity of devices per zone View/Edit Zone mode (Enabled/Disabled/Test/Test+Sounder)
Point	Basic	View Address & Device type View/Edit Device text label View/Edit Device mode (Enabled / disabled) View/Edit Device Zone allocation
		View Address & Device type View Device text label View Device Analogue Values
		Options
		Add/Remove
	Add/Remove	Add new device Remove a configured device
Log	-	View Event Log Erase Event Log
System	Strings	Edit Site Name Edit Installer Name Edit Installer/Maintenance Contact Number
	Clock	Edit Date & Time
	Users	Set Admin name label Set Admin password Set User name label Set User password Set the number of user passwords
Cause & Effect	Language	Set Panel Language (English/Espanyol/Romana/Portuguese)
		View / Enter / Delete Cause & Effect (See Cause & Effect Section)

		for details)
Local I/O	Zone Class A	View/Edit input (1-3) Text label View/Edit input (1-3) Zone allocation View/Edit input (1-3) Type (Alarm/Supervisory) View/Edit input (1-3) Status (Disabled/Enabled)
	Zone Class B	View/Edit input (1-6) Text label View/Edit input (1-6) Zone allocation View/Edit input (1-6) Type (Alarm/Supervisory) View/Edit input (1-6) Status (Disabled/Enabled)
	Input Class B	View/Edit input (1-3) Text label View/Edit input (1-3) Zone allocation View/Edit input (1-3) Type (Alarm/Supervisory) View/Edit input (1-3) Status (Disabled/Enabled)
	Relay	View/Edit output (1-3) Text label View/Edit output (1-3) Zone allocation View/Edit output (1-3) Type (Alarm/Trouble/Supervisory/Programmable) View/Edit output (1-3) Mode (Disabled/Enabled)
	Sounder Class A	View/Edit output (1) Text label View/Edit output (1) A. Grp allocation View/Edit output (1) Type (Sounder/Bell/Voltage) View/Edit output (1) Mode (Disabled/Enabled)
	Sounder Class B	View/Edit output (1-2) Text label View/Edit output (1-2) A. Grp allocation View/Edit output (1-2) Type (Sounder/Bell/Voltage) View/Edit output (1-2) Mode (Disabled/Enabled)
Day/Night	-	Configure day/night timer (add day settings)
LCD/LED	-	Test panel LEDs, LCD & Buzzer
Network	RS485 Network	View/Edit RS485 Port status (Disabled/Enabled local/Enabled Global) View/Edit Network Node Address View/Edit RS485 text label
	Printer	View/Edit Baud Rate (1200/2400/4800/9600/19200/38400/57600/115220) View/Edit Alarm printing (Disabled/Enabled) View/Edit Trouble printing (Disabled/Enabled) View/Edit Supervisory printing (Disabled/Enabled) View/Edit Button printing (Disabled/Enabled)
Delays		View/Edit Alarm Verification (Off/On) View/Edit Retard Time View/Edit Period Time View/Edit Sounder Delays (Off/On) View/Edit Flash Mute (Off/On) View/Edit Alarm Sequence (Off/On) View/Edit Ack. Time View/Edit Ext. Time View/Edit Resound 24H (Off/On) View/Edit Main Delayed (Off/On)
Alarm Group	Global Mode	View/Edit Relay Status (Disabled/Enabled) View/Edit Sounder Status (Disabled/Enabled)
	A. Grp Mode	View text label View/Edit A. Grp mode (All enabled/Sounder disabled/Relay disabled/All disabled)

Appendix C: Cause and Effects Settings Summary

The table below shows the list of options available for each type of input (cause) and Output (Effect):

Select CAUSE			
Input Type	Selection 1	Selection 2	Causes
Point	Loop Number (Port 1-26)	Point Address (1 - 254) Device Port (1-15)	<ul style="list-style-type: none"> Alarm Detector Alarm MCP Alarm Trouble Maintenance Supervisory ON Supervisory OFF
Local I/O	Local Module (1-26)	Module Port (1-6)	<ul style="list-style-type: none"> Trouble Alarm Supervisory ON Supervisory OFF
Zone	Zone Start (1 -254)	Zone End (1-254)	<ul style="list-style-type: none"> Alarm Detector Alarm MCP Alarm Trouble Maintenance Supervisory ON Supervisory OFF Mlt. devices in alarm
Panel	-	-	<ul style="list-style-type: none"> Alarm Detector Alarm MCP Alarm Trouble Maintenance Supervisory ON Supervisory OFF Mlt. devices in alarm Mlt. Zones in alarm Panel KeySwitch ON Panel KeySwitch OFF

Select EFFECT					
Output Type	Selection 1	Selection 2	Day Delay	Night Delay	Effect
Point	Loop number (1-26)	Point Address (1 - 254) Device Port (1-15)	(0-600)	(0-600)	<ul style="list-style-type: none"> March ANSI-3 Continuous Warning Beacon Switch off Enable Disable
Local I/O	Local module (1-26)	Module Port (1-6)	(0-600)	(0-600)	<ul style="list-style-type: none"> March ANSI-3 Continuous Warning Switch off Enable Disable
A.Group	A. Group start (1-254)	A. Group end (1-254)	(0-600)	(0-600)	<ul style="list-style-type: none"> March on sounders ANSI-3 on sounders Continuous on Sounders Activate Beacon Switch OFF SND/Beacon Switch ON Relays Switch OFF Relays March on Outputs ANSI-3 on Outputs

					<ul style="list-style-type: none"> • Continuous on Outputs • Switch off Output • Disable sounders • Enable sounders • Disable relays • Enable relays • Disable Output • Enable Output
Panel	-	-	(0-600)	(0-600)	<ul style="list-style-type: none"> • March on sounders • ANSI-3 on sounders • Continuous in sounders • Activate Beacon • Switch off SND/Beacon • Switch ON Relays • Switch OFF Relays • March on Outputs • ANSI-3 on Outputs • Continuous on Outputs • Switch off Output • Disable sounders • Enable sounders • Disable relays • Enable relays • Disable output • Enable Output

Operation and Maintenance Manual Modification History

Issue	Date	Changes
003	30/07/2019	<ul style="list-style-type: none"> - Edited acknowledgement sections due to MMP changes. - Edited function button sections due to MMP changes. - Edited UL programming table due to MMP changes. - Edited network sections due to MMP changes. - Removed VDOT-SCM-SCI device from manual. - Edited fault finding section.
004	25/9/2019	<ul style="list-style-type: none"> - Updated NAC disablement screens - Edited Verification operation - Added further information on zone test mode.
005	29/4/2022	Changes from UL final review
006	3/5/2022	Added Printer back into manual (Had been removed because of late docs from Mfr). Removed TCP info from menu tree
007	21/6/2023	Added VDOT-PY3, VDOT-PYH3, VDOT-H3 and VDOT-H3-H Information.