

Weatherproof Backbox Installation Instructions

The Pull Station may be mounted outdoors when used with the VDOT-WP / SGB-32C Weatherproof Backbox and Gasket. The VDOT-WP / SGB-32C Weatherproof Backbox is packaged with the Gasket sheet and four 8-32 screws. Gaskets must be placed onto both the Backbox and Pull Station. The drawings below show which pieces are used with the correct placement.

The outside edge of the Backbox Gasket should be aligned with the edge of the Backbox. The Gasket for the Backplate of the Pull Station can only fit with the large opening around the terminal block and the smaller end around the switch. The Gasket should be horizontally centered on the Backplate.

To apply,

Remove the appropriate piece from the Gasket sheet and place the adhesive side to the box or plate.

Before screwing the Pull Station Backplate to the Backbox, check to see that the two Gaskets do not overlap. If any overlap exists, gently pull up the Gasket and reposition. When the Gaskets are in proper position, continue with the procedure outlined on the Pull Station Instruction Sheet.

